



PowerFlex 4M Adjustable Frequency AC Drive

Bulletin Number 22F

Firmware Revision 1.xx...2.xx



Allen-Bradley

by ROCKWELL AUTOMATION

User Manual

Original Instructions

Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

IMPORTANT Identifies information that is critical for successful application and understanding of the product.

These labels may also be on or inside the equipment to provide specific precautions.



SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



ARC FLASH HAZARD: Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

The following icon may appear in the text of this document.



Identifies information that is useful and can help to make a process easier to do or easier to understand.

Rockwell Automation recognizes that some of the terms that are currently used in our industry and in this publication are not in alignment with the movement toward inclusive language in technology. We are proactively collaborating with industry peers to find alternatives to such terms and making changes to our products and content. Please excuse the use of such terms in our content while we implement these changes.

Summary of Changes

The information below summarizes the changes made for the September 2024 PowerFlex 4M Adjustable Frequency AC Drive User Manual, publication 22F-UM001E-EN-E.

Manual Updates

Description of New or Updated Information	Page(s)
Added Inclusive Language Acknowledgment	Important User Info
Added 140MT motor protectors to Bulletin 140M/140MT (Self-protected Combination Controller)/ UL489 Circuit Breakers	16
Added 140MT motor protectors and 100-E contactors to Minimum Recommended Branch Circuit Protective Devices	17
Updated Low Voltage Directive	31
Updated EMC Directive	31
Added EN 61800-5-1	32
Updated Programming and Parameters	39
Added 140MT motor protectors to Circuit Breakers	79
Added 140MT motor protectors, 100-E contactors, and DC fuses to Drive Ratings	80
Updated Approvals	82
Added Dynamic Brake Fuses to Dynamic Brake Modules	86
Updated Communication Option Kits	89
Added Programming Software	89

The information below summarizes the changes made for the June 2013 PowerFlex 4M Adjustable Frequency AC Drive User Manual, publication 22F-UM001D-EN-E.

Manual Updates

Description of New or Updated Information	Page(s)
Minimum Enclosure Volume column and new footnotes added	17, 80
Drive, Fuse & Circuit Breaker Ratings topic updated	79
Electronic Motor Overload Protection description updated	83

Summary of Changes

The information below summarizes the changes made for the July 2008 PowerFlex 4M Adjustable Frequency AC Drive User Manual, publication 22F-UM001C-EN-E.

Manual Updates

Description of New or Updated Information	Page(s)
Footnote (2) deleted from "EN61800-3 Second Environment" in Table 10	32
Note to stop drive before changing parameter t211 [Anlg In 0-10V Lo] removed	52
New option 13, I/O Control, for parameter t221 [Relay Out Sel] added	53
Fault description for F3 corrected	73
Corrected Table 19 by adding the 0.75 kW (1.0 HP) and 1.5 kW (2.0 HP) ratings for the 22F-RF025-BL EMC line filter	88
Description for bits 14, 13, and 12 of register address 8192 corrected	102
Information on reading register address 8192 clarified	102
Description for bits 6, 7, and 15 of register address 8192 updated	102
Information on reading register address 8193 clarified	103
Figure 17 , Network Wiring Diagram, updated	99
Guidelines on standard RS485 wiring practices added	99

The information below summarizes the changes made for the August 2007 PowerFlex 4M Adjustable Frequency AC Drive User Manual, publication 22F-UM001B-EN-E.

Manual Updates

Description of New or Updated Information	Page(s)
Input description and attention text for Multiple Digital Input Connection example corrected	28
Description for option 21 of parameter t221 [Relay Out Sel] corrected	53
Invalid catalog number for L Type Filter deleted	88 , 94
Graphic for the "Connecting an RS-485 Network" section corrected	107

Table of Contents

Preface	Overview	
		Who Should Use this Manual? 7
		Reference Materials 7
		Manual Conventions 8
		Drive Frame Sizes 8
		General Precautions 9
		Catalog Number Explanation 10
Chapter 1	Installation/Wiring	
		Opening the Cover 11
		Mounting Considerations 12
		AC Supply Source Considerations 13
		General Grounding Requirements 14
		Fuses and Circuit Breakers 16
		Power Wiring 18
		I/O Wiring Recommendations 22
		Start and Speed Reference Control 29
		EMC Instructions 31
Chapter 2	Start Up	
		Prepare For Drive Start-Up 33
		Integral Keypad 34
		Viewing and Editing Parameters 36
Chapter 3	Programming and Parameters	
		About Parameters 39
		Parameter Organization 40
		Display Group 41
		Basic Program Group 46
		Terminal Block Group 51
		Communications Group 55
		Advanced Program Group 57
		Parameter Cross Reference – by Name 69
Chapter 4	Troubleshooting	
		Drive Status 71
		Faults 71
		Fault Descriptions 73
		Common Symptoms and Corrective Actions 75
Appendix A	Supplemental Drive Information	
		Drive, Fuse & Circuit Breaker Ratings 79
		Specifications 80
Appendix B	Accessories and Dimensions	
		Product Selection 85
		Product Dimensions 90

Table of Contents

Appendix C	RS-485 (DSI) Protocol	
	Network Wiring	99
	Parameter Configuration	101
	Supported Modbus Function Codes	101
	Writing (06) Logic Command Data	102
	Writing (06) Reference	103
	Reading (03) Logic Status Data	103
	Reading (03) Feedback	103
	Reading (03) Drive Error Codes	104
	Reading (03) and Writing (06) Drive Parameters	104
	Additional Information	104
Appendix D	RJ45 DSI Splitter Cable	
	Connectivity Guidelines	105
	DSI Cable Accessories	106
	Connecting an RS-485 Network	107
Index	109

Overview

The purpose of this manual is to provide you with the basic information needed to install, start-up and troubleshoot the PowerFlex® 4M adjustable frequency AC drive.

Who Should Use this Manual?

This manual is intended for qualified personnel. You must be able to program and operate adjustable frequency AC drive devices. In addition, you must have an understanding of the parameter settings and functions.


Reference Materials

The following manuals are recommended for general drive information:

Resource	Description
PowerFlex AC Drive Performance Specifications per Ecodesign Regulation (EU) 2019/1781 and UK SI 2021 No. 745 Technical Data, publication PFLEX-TD003	Provides specifications per Ecodesign Regulation (EU) 2019/1781 and UK SI 2021 No. 745, including efficiency class.
Guarding Against Electrostatic Damage (ESD) Service Bulletin, publication 8000-4.5.2	Provides information on causes of ESD, and how you can guard against its effects.
Wiring and Grounding for Pulse Width Modulated (PWM) AC Drives Installation Instructions, publication DRIVES-IN001	Provides basic information that is needed to wire and ground PWM AC drives properly.
Preventive Maintenance Checklist of Industrial Control and Drive System Equipment Technical Data, publication DRIVES-TD001	Provides checklist on performing preventive maintenance for industrial control and drive system equipment.
Safety Guidelines for the Application, Installation, and Maintenance of Solid-State Control Installation Instructions, publication SGI-1.1	Provide general guidelines for the application, installation, and maintenance of solid-state control in the form of individual devices or packaged assemblies incorporating solid-state components.
Industrial Automation Wiring and Grounding Guidelines, publication 1770-4.1	Provides general guidelines for installing a Rockwell Automation industrial system.

Manual Conventions

- In this manual we refer to the PowerFlex 4M Adjustable Frequency AC Drive as: drive, PowerFlex 4M or PowerFlex 4M Drive.
- Parameter numbers and names are shown in this format:



- The following words are used throughout the manual to describe an action:

Word	Meaning
Can	Possible, able to do something
Cannot	Not possible, not able to do something
May	Permitted, allowed
Must	Unavoidable, you must do this
Shall	Required and necessary
Should	Recommended
Should Not	Not Recommended

Drive Frame Sizes

Similar PowerFlex 4M drive sizes are grouped into frame sizes to simplify spare parts ordering, dimensioning, and so on. A cross-reference of drive catalog numbers and their respective frame sizes is provided in [Appendix B](#).

General Precautions



ATTENTION: To avoid an electric shock hazard, verify that the voltage on the bus capacitors has discharged before performing any work on the drive. Measure the DC bus voltage at the –DC and +DC terminals on the Power Terminal Block (see [Chapter 1](#) Power Terminal descriptions). The voltage must be zero.

Darkened LEDs or a darkened LCD display is not an indication that capacitors have discharged to safe voltage levels.



ATTENTION: Only qualified personnel familiar with adjustable frequency AC drives and associated machinery should plan or implement the installation, start-up and subsequent maintenance of the system. Failure to comply may result in personal injury and/or equipment damage.



ATTENTION: This drive contains Electrostatic Discharge (ESD) sensitive parts and assemblies. Static control precautions are required when installing, testing, servicing or repairing this assembly. Component damage may result if ESD control procedures are not followed. If you are not familiar with static control procedures, reference publication [8000-4.5.2](#), “Guarding Against Electrostatic Damage” or any other applicable ESD protection handbook.



ATTENTION: An incorrectly applied or installed drive can result in component damage or a reduction in product life. Wiring or application errors, such as, undersizing the motor, incorrect or inadequate AC supply, or excessive ambient temperatures may result in malfunction of the system.



ATTENTION: The bus regulator function is extremely useful for preventing nuisance overvoltage faults resulting from aggressive decelerations, overhauling loads, and eccentric loads. However, it can also cause either of the following two conditions to occur.

1. Fast positive changes in input voltage or imbalanced input voltages can cause uncommanded positive speed changes;
2. Actual deceleration times can be longer than commanded deceleration times.

However, a “Stall Fault” is generated if the drive remains in this state for 1 minute. If this condition is unacceptable, the bus regulator must be disabled (see parameter [A441](#)). In addition, installing a properly sized dynamic brake resistor will provide equal or better performance in most cases.

Catalog Number Explanation

1...3	4	5	6...8	9	10	11	12	13...14
22F	-	D	8P7	N	1	1	3	AA
Drive	Dash	Voltage Rating	Rating	Enclosure	HIM	Emission Class	Type	Optional

Code

22F PowerFlex 4M

Code Version

3 No Brake IGBT
4 Standard

Code Voltage Phase

V 120V AC 1
A 240V AC 1
B 240V AC 3
D 480V AC 3

Code Rating

0 Not Filtered
1 Filtered

Code Interface Module

1 Fixed Keypad

Code Purpose

AA Reserved for
... custom firmware
ZZ

Code Enclosure

N Panel Mount - IP20 (NEMA Type Open)

Output Current @ 100...120V Input

Code	Amps	kW (HP)
1P6	1.6	0.2 (0.25)
2P5	2.5	0.4 (0.5)
4P5	4.5	0.75 (1.0)
6P0	6.0	1.1 (1.5)

Output Current @ 200...240V Input

Code	Amps	kW (HP)
1P6	1.6	0.2 (0.25)
2P5	2.5	0.4 (0.5)
4P2	4.2	0.75 (1.0)
8P0	8.0	1.5 (2.0)
011	11.0	2.2 (3.0)
012	12.0	2.2 (3.0)
017	17.5	3.7 (5.0)
025	25.0	5.5 (7.5)
033	33.0	7.5 (10.0)

Output Current @ 380...480V Input

Code	Amps	kW (HP)
1P5	1.5	0.4 (0.5)
2P5	2.5	0.75 (1.0)
4P2	4.2	1.5 (2.0)
6P0	6.0	2.2 (3.0)
8P7	8.7	3.7 (5.0)
013	13.0	5.5 (7.5)
018	18.0	7.5 (10.0)
024	24.0	10.0 (15.0)

Additional accessories, options, and adapters are available. See [Appendix B](#) for details.

Installation/Wiring

This chapter provides information on mounting and wiring the PowerFlex 4M drive.


Most startup difficulties are the result of incorrect wiring. Every precaution must be taken to assure that the wiring is done as instructed. All items must be read and understood before the actual installation begins.



ATTENTION: The following information is merely a guide for proper installation. Rockwell Automation, Inc. cannot assume responsibility for the compliance or the noncompliance to any code, national, local or otherwise for the proper installation of this drive or associated equipment. A hazard of personal injury and/or equipment damage exists if codes are ignored during installation.

Opening the Cover

1. Press and hold in the tabs on each side of the cover.
2. Pull the cover out and up to release.



Mounting Considerations

- Mount the drive upright on a flat, vertical, and level surface.
 - Install on 35 mm (1.38 in.) DIN rail (for frames A and B).
 - or
 - Install with screws.


Table 1 – Screw Mounting Recommendations

Min Panel Thickness	Screw Size	Mounting Torque
1.9 mm (0.0747 in.)	M4 (#8-32)	1.56...1.96 N•m (14...17 lb•in)

- Protect the cooling fan by avoiding dust or metallic particles.
- Do not expose to a corrosive atmosphere.
- Protect from moisture and direct sunlight.

Minimum Mounting Clearances

See [Appendix B](#) for mounting dimensions.



Ambient Operating Temperatures

Table 2 – Enclosure and Clearance Requirements

Horizontal Clearance between drives	Ambient Temperature	
	Minimum	Maximum
0 mm (0 in.) and greater	-10 °C (14 °F)	40 °C (104 °F)
25 mm (0.08 in.) and greater	-10 °C (14 °F)	50 °C (122 °F)

The drive enclosure is rated IP20, NEMA/UL Type Open.

Storage

- Store within an ambient temperature range of $-40\dots+85\text{ }^{\circ}\text{C}$ ($-40\dots+185\text{ }^{\circ}\text{F}$).
- Store within a relative humidity range of $0\dots95\%$, noncondensing.
- Do not expose to a corrosive atmosphere.

AC Supply Source Considerations

Ungrounded Distribution Systems



ATTENTION: PowerFlex 4M drives contain protective MOVs that are referenced to ground. These devices must be disconnected if the drive is installed on an ungrounded or resistive grounded distribution system.

Disconnecting MOVs

To help prevent drive damage, the MOVs connected to ground shall be disconnected if the drive is installed on an ungrounded distribution system where the line-to-ground voltages on any phase could exceed 125% of the nominal line-to-line voltage. To disconnect these devices, remove the jumper that is shown in [Figure 1](#) and [Figure 2](#).

1. Turn the screw counterclockwise to loosen.
2. Pull the jumper completely out of the drive chassis.
3. Tighten the screw to keep it in place.

Figure 1 – Jumper Location (Frame A Shown)

Important:
Tighten screw after
jumper removal.





Figure 2 – Phase to Ground MOV Removal



Input Power Conditioning

The drive is suitable for direct connection to input power within the rated voltage of the drive (see [Appendix A](#)). Listed in [Table 3](#) are certain input power conditions that can cause component damage or reduction in product life. If any of the conditions exist, as described in [Table 3](#), install one of the devices that are listed under the heading Corrective Action on the line side of the drive.

Important: Only one device per branch circuit is required. It should be mounted closest to the branch and sized to handle the total current of the branch circuit.

Table 3 – Input Power Conditions


Input Power Condition	Corrective Action
Low Line Impedance (less than 1% line reactance)	Install Line Reactor ⁽¹⁾ or Isolation Transformer
Greater than 120 kVA supply transformer	
Line has power factor correction capacitors	
Line has frequent power interruptions	
Line has intermittent noise spikes in excess of 6000V (lightning)	
Phase to ground voltage exceeds 125% of normal line-to-line voltage	Remove MOV jumper to ground or Install Isolation Transformer with grounded secondary if necessary.
Ungrounded distribution system	

⁽¹⁾ See [Appendix B](#) for accessory ordering information.

General Grounding Requirements

The drive Safety Ground - \oplus (PE) must be connected to system ground. Ground impedance must conform to the requirements of national and local industrial safety regulations and/or electrical codes. The integrity of all ground connections should be periodically checked.

Figure 3 – Typical Grounding



Ground Fault Monitoring

If a system ground fault monitor (RCD) is to be used, only Type B (adjustable) devices should be used to avoid nuisance tripping.

Safety Ground - \oplus (PE)

This is the safety ground for the drive that is required by code. One of these points must be connected to an adjacent building steel (girder, joist), a floor ground rod, or busbar. Grounding points must comply with national and local industrial safety regulations and/or electrical codes.

Motor Ground

The motor ground must be connected to one of the ground terminals on the drive.

Shield Termination - SHLD

Either of the safety ground terminals that are located on the power terminal block provides a grounding point for the motor cable shield. The **motor cable** shield connected to one of these terminals (drive end) should also be connected to the motor frame (motor end). Use a shield terminating or EMI clamp to connect the shield to the safety ground terminal. The conduit box option may be used with a cable clamp for a grounding point for the cable shield.

When a shielded cable is used for **control and signal wiring**, the shield should be grounded at the source end only, not at the drive end.

RFI Filter Grounding

Using single-phase drives with an integral filter, or an external filter with any drive rating, can result in relatively high ground leakage currents. Therefore, the **filter must only be used in installations with grounded AC supply systems and be permanently installed and solidly grounded** (bonded) to the building power distribution ground. Ensure that the incoming supply neutral is solidly connected (bonded) to the same building power distribution ground. Grounding must not rely on flexible cables and should exclude any form of plug or socket that would permit inadvertent disconnection. Some local codes may require redundant ground connections. The integrity of all connections should be periodically checked.

Fuses and Circuit Breakers

The PowerFlex 4M drive does not provide branch short circuit protection. This product should be installed with either input fuses or an input circuit breaker. National and local industrial safety regulations and/or electrical codes may determine additional requirements for these installations.



ATTENTION: To guard against personal injury and/or equipment damage caused by improper fusing or circuit breaker selection, use only the recommended line fuses/circuit breakers specified in this section.

Fusing

The PowerFlex 4M drive has been UL tested and approved for use with input fuses. The ratings in the table that follows are the maximum recommended values for use with each drive rating. The devices that are listed in this table are provided to serve as a guide.

Bulletin 140M/140MT (Self-protected Combination Controller)/ UL489 Circuit Breakers

■ When using Bulletin 140M/140MT or UL489 rated circuit breakers, the guidelines that are listed below must be followed to meet the NEC requirements for branch circuit protection.

- • Bulletin 140M/140MT can be used in single and group motor applications.
- • Bulletin 140M/140MT can be used upstream from the drive **without** the need for fuses.

Table 4 – Minimum Recommended Branch Circuit Protective Devices

Voltage Rating	Drive Rating kW (HP)	Fuse Rating⁽¹⁾ Amps	140M/140MT^{(2)/(3)} Catalog Number	Recommended MCS Contactors Catalog Number	Min Enclosure Volume⁽⁴⁾ Inches³
120V AC – 1-phase	0.2 (0.25)	10	140M-C2E-C10 140MT-C3E-C10	100-C09 100-E09	1655
	0.4 (0.5)	15	140M-C2E-C16 140MT-C3E-C16	100-C12 100-E12	1655
	0.75 (1.0)	30	140M-D8E-C20 140MT-D9E-C20	100-C23 100-E26	1655
	1.1 (1.5)	40	140M-F8E-C32	100-C30 100-E30	1655
240V AC – 1-phase	0.2 (0.25)	10	140M-C2E-B63 140MT-C3E-B63	100-C09 100-E09	1655
	0.4 (0.5)	10	140M-C2E-C10 140MT-C3E-C10	100-C09 100-E09	1655
	0.75 (1.0)	15	140M-C2E-C16 140MT-C3E-C16	100-C12 100-E12	1655
	1.5 (2.0)	35	140M-D8E-C25 140MT-D9E-C25	100-C23 100-E26	1655
	2.2 (3.0)	40	140M-F8E-C32	100-C30 100-E30	1655
240V AC – 3-phase	0.2 (0.25)	3	140M-C2E-B25 140MT-C3E-B25	100-C09 100-E09	1655
	0.4 (0.5)	6	140M-C2E-B40 140MT-C3E-B40	100-C09 100-E09	1655
	0.75 (1.0)	10	140M-C2E-B63 140MT-C3E-B63	100-C09 100-E09	1655
	1.5 (2.0)	15	140M-C2E-C16 140MT-C3E-C16	100-C12 100-E12	1655
	2.2 (3.0)	25	140M-D8E-C20 140MT-D9E-C20	100-C23 100-E26	1655
	3.7 (5.0)	35	140M-D8E-C25 140MT-D9E-C25	100-C23 100-E26	1655
	5.5 (7.5)	45	140M-F8E-C32	100-C37 100-E38	3441
	7.5 (10.0)	60	140M-F8E-C45	100-C60 100-E52	3441

Table 4 – Minimum Recommended Branch Circuit Protective Devices (Continued)

Voltage Rating	Drive Rating kW (HP)	Fuse Rating ⁽¹⁾ Amps	140M/140MT ⁽²⁾⁽³⁾ Catalog Number	Recommended MCS Contactors Catalog Number	Min Enclosure Volume ⁽⁴⁾ Inches ³
480V AC – 3-phase	0.4 (0.5)	3	140M-C2E-B25	100-C09	1655
			140MT-C3E-B25	100-E09	
	0.75 (1.0)	6	140M-C2E-B40	100-C09	1655
			140MT-C3E-B40	100-E09	
	1.5 (2.0)	10	140M-C2E-C10	100-C09	1655
			140MT-C3E-C10	100-E09	
	2.2 (3.0)	10	140M-C2E-C10	100-C09	1655
			140MT-C3E-C10	100-E-0	
3.7 (5.0)	15	140M-C2E-C16	100-C12	1655	
		140MT-C3E-C6	100-E12		
5.5 (7.5)	25	140M-D8E-C20	100-C23	3441	
		140MT-D9E-C20	100-E26		
7.5 (10.0)	30	140M-F8E-C25	100-C23	3441	
			100-E26		
11.0 (15.0)	50	140M-F8E-C32	100-C30	3441	
			100-E30		

- (1) Recommended Fuse Type: UL Class J, RK1, T, or Type BS88; 600V (550V) or equivalent.
- (2) The AIC ratings of the Bulletin 140M/140MT Motor Protector Circuit Breakers may vary. See the Motor Protection Circuit Breaker and Motor Circuit Protector Specifications Technical Data, publication [140-TD005](#) or [140M-TD002](#).
- (3) Manual Self-protected (Type E) Combination Motor Controller, UL Listed for 208 Wye or Delta, 240 Wye or Delta, 480Y/277 or 600Y/347. Not UL listed for use on 480V or 600V Delta/Delta, corner ground, or high-resistance ground systems.
- (4) When using a Manual Self-protected (Type E) Combination Motor Controller, the drive must be installed in a ventilated or non-ventilated enclosure with the minimum volume specified in this column. Application specific thermal considerations may require a larger enclosure.

Power Wiring



ATTENTION: National Codes and standards (NEC, VDE, BSI, and so on) and local codes outline provisions for safely installing electrical equipment. Installation must comply with specifications regarding wire types, conductor sizes, branch circuit protection and disconnect devices. Failure to do so may result in personal injury and/or equipment damage.



ATTENTION: To avoid a possible shock hazard caused by induced voltages, unused wires in the conduit must be grounded at both ends. For the same reason, if a drive sharing a conduit is being serviced or installed, all drives using this conduit should be disabled. This will help minimize the possible shock hazard from “cross coupled” power leads.

Motor Cable Types Acceptable for 200...600 Volt Installations

General

Various cable types are acceptable for drive installations. For many installations, unshielded cable is adequate, provided it can be separated from sensitive circuits. As an approximate guide, allow a spacing of 0.3 meters (1 foot) for every 10 meters (32.8 feet) of length. In all cases, long parallel runs must be avoided. Do not use cables with an insulation thickness less than 15 mils (0.4 mm/0.015 in.). Do not route more than three sets of motor leads in one conduit to minimize “cross talk”. If more than three drive/motor connections per conduit are required, a shielded cable must be used.

UL installations in 50 °C (122 °F) ambient must use 600V, 75 °C or 90 °C (167 °F or 194 °F) wire.

UL installations in 40 °C (104 °F) ambient should use 600V, 75 °C or 90 °C (167 °F or 194 °F) wire.

Use copper wire only. Wire gauge requirements and recommendations are based on 75 °C (167 °F). Do not reduce the wire gauge when using higher temperature wire.

Unshielded

THHN, THWN, or similar wire is acceptable for drive installation in dry environments provided adequate free air space and/or conduit fill rates limits are provided. **Do not use THHN or similarly coated wire in wet areas.** Any wire that is chosen must have a minimum insulation thickness of 15 mils (0.4 mm/0.015 in.) and should not have large variations in insulation concentricity.

Shielded

Location	Rating/Type	Description
Standard (Option 1)	600V, 75 °C or 90 °C (167 °F or 194 °F) RHH/RHW-2 Belden 29501...29507 or equivalent	<ul style="list-style-type: none"> • Four tinned copper conductors with XLPE insulation • Foil shield and tinned copper drain wire with 85% braid coverage • PVC jacket
Standard (Option 2)	Tray rated 600V, 75 °C or 90 °C (167 °F or 194 °F) RHH/RHW-2 Shawflex 2ACD/3ACD or equivalent	<ul style="list-style-type: none"> • Three tinned copper conductors with XLPE insulation • 5 mil single helical copper tape (25% overlap min.) with three bare copper grounds in contact with shield • PVC jacket
Class I and II; Division I and II	Tray rated 600V, 75 °C or 90 °C (167 °F or 194 °F) RHH/RHW-2	<ul style="list-style-type: none"> • Three tinned copper conductors with XLPE insulation • 5 mil single helical copper tape (25% overlap min) with three bare copper grounds in contact with shield • PVC copper grounds on 6.0 mm² (10 AWG) and smaller

Reflected Wave Protection

The drive should be installed as close to the motor as possible. Installations with long motor cables may require the addition of external devices to limit voltage reflections at the motor (reflected wave phenomena). See [Table 5](#) for recommendations.

The reflected wave data applies to all frequencies 2...10 kHz.

For 240V ratings, reflected wave effects do not need to be considered.

Table 5 – Maximum Cable Length Recommendations

Reflected Wave		
380...480V Ratings	Motor Insulation Rating	Motor Cable Only ⁽¹⁾
	1000 Vp-p	15 m (49 ft)
	1200 Vp-p	40 m (131 ft)
	1600 Vp-p	170 m (558 ft)

⁽¹⁾ Longer cable lengths can be achieved by installing devices on the output of the drive. Consult the factory for recommendations.

Output Disconnect

The drive is intended to be commanded by control input signals that will start and stop the motor. A device that routinely disconnects then reapplies output power to the motor for the purpose of starting and stopping the motor should not be used. If it is necessary to disconnect power to the motor with the drive outputting power, an auxiliary contact should be used to simultaneously disable drive control run commands.


Power Terminal Block

The drive utilizes a finger guard over the power wiring terminals. To remove:


1. Press in and hold the locking tab.
2. For the finger guard on the top of the drive, slide it down and out. For the finger guard at the bottom of the drive, slide it up and out.

Replace the finger guard when wiring is complete.

Figure 4 – Power Terminal Block



Terminal	Description
R/L1, S/L2	1-phase Input
R/L1, S/L2, T/L3	3-phase Input
P1 ⁽¹⁾ , P2 ⁽¹⁾	DC Bus Inductor Connection (Frame C drives only.) The Frame C drive is shipped with a jumper between Terminals P1 and P2. Remove this jumper only when a DC Bus Inductor will be connected. Drive will not power up without a jumper or inductor connected.
U/T1	To Motor U/T1
V/T2	To Motor V/T2 =
W/T3	To Motor W/T3
DC+ ⁽²⁾ , DC- ⁽²⁾	DC Bus Connection
BR+ ⁽¹⁾ , BR- ⁽¹⁾	Dynamic Brake Resistor Connection
⊕	Safety Ground - PE



Switch any two motor leads to change forward direction.

(1) For Frame C only, 5.5 kW (7.5 HP) ratings and higher.

(2) Not applicable to 120V, 1-phase drives.

Table 6 – Power Terminal Block Specifications

Frame	Maximum Wire Size ⁽¹⁾	Minimum Wire Size ⁽¹⁾	Torque
A	3.3 mm ² (12 AWG)	0.8 mm ² (18 AWG)	1.4...1.6 N•m (12...14 lb•in)
B	8.4 mm ² (8 AWG)	0.8 mm ² (18 AWG)	1.6...1.9 N•m (14...17 lb•in)
C	13.3 mm ² (6 AWG)	3.3 mm ² (12 AWG)	2.7...3.2 N•m (24...28 lb•in)

⁽¹⁾ Maximum/minimum sizes that the terminal block will accept - These are not recommendations.

Motor Start/Stop Precautions



ATTENTION: A contactor or other device that routinely disconnects and reapplies the AC line to the drive to start and stop the motor can cause drive hardware damage. The drive is designed to use control input signals that will start and stop the motor. If used, the input device must not exceed one operation per minute, or drive damage can occur.



ATTENTION: The drive start/stop control circuitry includes solid-state components. If hazards due to accidental contact with moving machinery or unintentional flow of liquid, gas or solids exist, an additional hardwired stop circuit may be required to remove the AC line to the drive. When the AC line is removed, there will be a loss of any inherent regenerative braking effect that might be present - the motor will coast to a stop. An auxiliary braking method may be required.

I/O Wiring Recommendations

Important points to remember about I/O wiring:

- Always use copper wire.
- Wire with an insulation rating of 600V or greater is recommended.
- Control and signal wires should be separated from power wires by at least 0.3 meters (1 foot).

Important: I/O terminals labeled “Common” are not referenced to the safety ground (PE) terminal and are designed to greatly reduce common mode interference.



ATTENTION: Driving the 4...20mA analog input from a voltage source could cause component damage. Verify proper configuration before applying input signals.

Control Wire Types

Table 7 – Recommended Control and Signal Wire⁽¹⁾

Wire Type(s)	Description	Minimum Insulation Rating
Belden 8760/9460 (or equivalent)	0.8 mm ² (18 AWG), twisted-pair, 100% shield with drain	300V 60 °C (140 °F)
Belden 8770 (or equivalent)	0.8 mm ² (18 AWG), 3 conductor, shielded for remote pot only	

⁽¹⁾ If the wires are short and contained within a cabinet which has no sensitive circuits, the use of shielded wire may not be necessary, but is always recommended.

I/O Terminal Block

Table 8 – I/O Terminal Block Specifications

Maximum Wire Size ⁽¹⁾	Minimum Wire Size ⁽¹⁾	Torque
1.3 mm ² (16 AWG)	0.2 mm ² (24 AWG)	0.5...0.8 N•m (4.4...7 lb•in)

⁽¹⁾ Maximum/minimum sizes that the terminal block will accept - These are not recommendations.



Maximum Control Wire Recommendations

Do not exceed a control wiring length of 30 meters (100 feet). Control signal cable length is highly dependent on the electrical environment and installation practices. To improve noise immunity, the I/O terminal block Common must be connected to ground terminal/protective earth. If using the RS-485 (DSI) port, I/O Terminal 16 should also be connected to ground terminal/protective earth.

Figure 5 – Control Wiring Block Diagram


(1) Important: I/O Terminal 01 is always a coast-to-stop input except when P106 [Start Source] is set to “3-Wire” control. In three wire control, I/O Terminal 01 is controlled by P107 [Stop Mode]. All other stop sources are controlled by P107 [Stop Mode].

Important: The drive is shipped with a jumper that is installed between I/O Terminals 01 and 11. Remove this jumper when using I/O Terminal 01 as a stop or enable input.

(2) Two wire control shown. For three-wire control use a momentary input  on I/O Terminal 02 to command a start. Use a maintained input  for I/O Terminal 03 to change direction.

P106 [Start Source]	Stop	I/O Terminal 01 Stop
Keypad	Per P107	Coast
3-wire	Per P107	Per P107
2-wire	Per P107	Coast
RS-485 Port	Per P107	Coast

	30V DC	125V AC	240V AC
Resistive	3.0 A	3.0 A	3.0 A
Inductive	0.5 A	0.5 A	0.5 A













No.	Signal	Default	Description	Param.
R1	Relay N.O.	Fault	Normally open contact for output relay.	t221
R2	Relay Common	–	Common for output relay.	
R3	Relay N.C.	Fault	Normally closed contact for output relay.	t221
Sink/Source DIP Switch		Source (SRC)	Inputs can be wired as Sink (SNK) or Source (SRC) via DIP switch setting.	
01	Stop (1)	Coast	The factory-installed jumper or a normally closed input must be present for the drive to start.	P106 (1)
02	Start/Run FWD	Not Active	Command comes from the integral keypad by default. To disable reverse operation, see A095 [Reverse Disable].	P106 , P107
03	Direction/Run REV	Not Active		P106 , P107 , A434
04	Digital Common	–	For digital inputs. Electronically isolated with digital inputs from analog I/O.	
05	Digital Input 1	Preset Freq	Program with t201 [Digital In1 Sel].	t201
06	Digital Input 2	Preset Freq	Program with t202 [Digital In2 Sel].	t202
11	+24V DC	–	Drive supplied power for digital inputs. Maximum output current is 100 mA.	







No.	Signal	Default	Description	Param.
12	+10V DC	–	Drive supplied power for 0...10V external potentiometer. Maximum output current is 15 mA.	P108
13	0...10V In ⁽³⁾	Not Active	For external 0...10V input supply (input impedance = 100 kΩ) or potentiometer wiper.	P108
14	Analog Common	–	For 0...10V In or 4...20mA In. Electronically isolated with analog inputs from digital I/O.	
15	4...20mA In ⁽³⁾	Not Active	For external 4...20mA input supply (input impedance = 250 Ω).	P108
16	RS-485 (DSI) Shield	–	Terminal should be connected to safety ground - PE when using the RS-485 (DSI) communications port.	

⁽³⁾ Only one analog frequency source may be connected at a time. If more than one reference is connected simultaneously, an undetermined frequency reference will result.



I/O Wiring Examples

Input	Connection Example	
Potentiometer 1...10 kΩ Pot. Recommended (2 Watt minimum)	P108 [Speed Reference] = 2 "0-10V Input" 	
Analog Input 0...10V, 100 kΩ impedance 4...20 mA, 100 Ω impedance	Voltage P108 [Speed Reference] = 2 "0-10V Input" 	Current P108 [Speed Reference] = 3 "4-20mA Input" 
	Analog Input, PTC For Drive Fault Wire the PTC and External Resistor (typically matched to the PTC Hot Resistance) to I/O Terminals 12, 13, 14. Wire R2/R3 Relay Output (SRC) to I/O Terminals 5 and 11. t201 [Digital In1 Sel] = 3 "Aux Fault" t221 [Relay Out Sel] = 10 "Above Anlg V" t222 [Relay Out Level] = % Voltage Trip  <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-left: auto; margin-right: auto;"> $V_{\text{Trip}} = \frac{R_{\text{PTC (hot)}}}{R_{\text{PTC (hot)}} + R_e} \times 100$ </div>	

Input	Connection Example	
<p>2-wire SRC Control - Non-reversing</p> <p>P106 [Start Source] = 2, 3, or 4</p> <p>Input must be active for the drive to run. When input is opened, the drive will stop as specified by P107 [Stop Mode].</p> <p>If desired, a User Supplied 24V DC power source can be used. See the “External Supply (SRC)” example.</p>	<p>Internal supply (SRC)</p> 	<p>External supply (SRC)</p>  <p>Each digital input draws 6 mA.</p>
<p>2-wire SNK Control - Non-reversing</p>	<p>Internal supply (SNK)</p> 	
<p>2-wire SRC Control - Run FWD/Run REV</p> <p>P106 [Start Source] = 2, 3, or 4</p> <p>Input must be active for the drive to run. When input is opened, the drive will stop as specified by P107 [Stop Mode].</p> <p>If both Run Forward and Run Reverse inputs are closed simultaneously, an undetermined state could occur.</p>	<p>Internal supply (SRC)</p> 	<p>External supply (SRC)</p>  <p>Each digital input draws 6 mA.</p>
<p>2-wire SNK Control - Run FWD/Run REV</p>	<p>Internal supply (SNK)</p> 	


Input	Connection Example	
<p>3-wire SRC Control - Non-reversing</p> <p>P106 [Start Source] = 1</p> <p>A momentary input will start the drive. A stop input to I/O Terminal 01 will stop the drive as specified by P107 [Stop Mode].</p>	<p>Internal supply (SRC)</p> 	<p>External supply (SRC)</p>  <p>Each digital input draws 6 mA.</p>
<p>3-wire SNK Control - Non-reversing</p>	<p>Internal supply (SNK)</p> 	
<p>3-wire SRC Control - Reversing</p> <p>P106 [Start Source] = 1</p> <p>A momentary input will start the drive. A stop input to I/O Terminal 01 will stop the drive as specified by P107 [Stop Mode]. I/O Terminal 03 determines direction.</p>	<p>Internal supply (SRC)</p> 	<p>External supply (SRC)</p>  <p>Each digital input draws 6 mA.</p>
<p>3-wire SNK Control - Reversing</p>	<p>Internal supply (SNK)</p> 	

Typical Multiple Drive Connection Examples

Input	Connection Example
<p>Multiple Digital Input Connections</p> <p>Customer Inputs can be wired per External Supply (SRC) or Internal Supply (SNK) examples on page 26.</p>	 <p>When connecting a single input such as Run, Stop, Reverse, or Preset Speeds to multiple drives, it is important to connect I/O Terminal 04 common together for all drives. If they are to be tied into another common (such as earth ground or separate apparatus ground) only one point of the daisy chain of I/O Terminal 04 should be connected.</p> <p>ATTENTION: Digital inputs on multiple drives should not be tied together when using SNK (Internal Supply) mode. In SNK mode, if power is removed from one drive, inadvertent operation of other drives that share the same I/O Common connection may occur.</p>
<p>Multiple Analog Connections</p>	 <p>When connecting a single potentiometer to multiple drives it is important to connect I/O Terminal 14 common together for all drives. I/O Terminal 14 common and I/O Terminal 13 (potentiometer wiper) should be daisy chained to each drive. All drives must be powered up for the analog signal to be read correctly.</p>


Start and Speed Reference Control

The drive speed command can be obtained from a number of different sources. The source is normally determined by P108 [Speed Reference]. However, when t201 or t202 [Digital Inx Sel] is set to option 2, 4, 5, or 6, and the digital input is active, t201 or t202 will override the speed reference that is commanded by P108 [Speed Reference]. See the chart below for the override priority.



Accel/Decel Selection

The selection of Accel/Decel rates can be made through digital inputs, RS-485 (DSI) communications and/or parameters.



EMC Instructions

CE Conformity

Conformity with the Low Voltage (LV) Directive and Electromagnetic Compatibility (EMC) Directive has been demonstrated using harmonized European Norm (EN) standards published in the Official Journal of the European Communities. PowerFlex drives comply with the EN standards that are listed below when installed according to the user manual.

CE Declarations of Conformity are available online at:

rok.auto/certifications

Low Voltage Directive (2014/35/EU)

- EN 61800-5-1 Adjustable speed electrical power drive systems – Part 5-1: Safety requirements – Electrical, thermal, and energy

Table 9 – Pollution Degree Ratings According to EN 61800-5-1

Pollution Degree	Description
1	No pollution or only dry, non-conductive pollution occurs. The pollution has no influence.
2	Normally, only non-conductive pollution occurs. Occasionally, however, a temporary conductivity that is caused by condensation is to be expected when the drive is out of operation.

EMC Directive (2014/30/EU)

- EN 61800-3 Adjustable speed electrical power drive systems Part 3: EMC requirements and specific test methods.

General Notes

- The motor cable should be kept as short as possible to avoid electromagnetic emission and capacitive currents.
- Use of line filters in ungrounded systems is not recommended.
- Conformity of the drive with CE EMC requirements does not guarantee an entire machine installation complies with CE EMC requirements. Many factors can influence total machine/installation compliance.

Essential Requirements for CE Compliance

Conditions 1...3 listed below **must be** satisfied for PowerFlex drives to meet the requirements of EN 61800-3.

1. Grounding as described in [Figure 6](#). See [RFI Filter Grounding on page 16](#) for additional grounding recommendations.
2. Output power, control (I/O), and signal wiring must be braided, shielded cable with a coverage of 75% or better, metal conduit or equivalent attenuation.
3. Allowable cable length in [Figure 10](#) is not exceeded.

Table 10 – Allowable Cable Length


Filter Type	EN61800-3 Second Environment	EN61800-3 First Environment Restricted Distribution ⁽²⁾	EN61800-3 First Environment Unrestricted Distribution ⁽³⁾
Integral, 240V	5 m (16 ft)	5 m (16 ft)	1 m (3 ft)
Integral, 480V	10 m (33 ft)	–	–
External - S Type ⁽¹⁾	5 m (16 ft)	5 m (16 ft)	1 m (3 ft)
External - L Type ⁽¹⁾	100 m (328 ft)	100 m (328 ft)	25 m (82 ft)

(1) See [Appendix B](#) for details on optional external filters.

(2) Equivalent to EN 55011 Class A.

(3) Equivalent to EN 55011 Class B.

Figure 6 – Connections and Grounding



(1) First Environment Unrestricted Distribution installations require a shielded enclosure. Keep the wire length as short as possible between the enclosure entry point and the EMI filter.

(2) Integral EMI filters are available on 240V, 1-phase drives and 380V, 3-phase drives.

EN 61000-3-2

- 0.75 kW (1 HP) 240V 1-phase and 3-phase drives and 0.4 kW (0.5 HP) 240V 1-phase drives are suitable for installation on a private low voltage power network. Installations on a public low voltage power network may require additional external harmonic mitigation.
- Other drive ratings meet the current harmonic requirements of EN 61000-3-2 without additional external mitigation.

EN 61800-5-1

A DC fuse is required when connecting to the dynamic brake terminal (BR-) or DC bus terminals (DC+, DC-). Place the fuse close to the terminal.

Start Up

This chapter describes how to start up the PowerFlex 4M drive. To simplify drive setup, the most commonly programmed parameters are organized in a single Basic Program Group.

Important: Read the [General Precautions](#) section before proceeding.



ATTENTION: Power must be applied to the drive to perform the following start-up procedures. Some of the voltages present are at incoming line potential. To avoid electric shock hazard or damage to equipment, only qualified service personnel should perform the following procedure. Thoroughly read and understand the procedure before beginning. If an event does not occur while performing this procedure, **Do Not Proceed. Remove All Power** including user supplied control voltages. User supplied voltages may exist even when main AC power is not applied to the drive. Correct the malfunction before continuing.

Prepare For Drive Start-Up

Before Applying Power to the Drive

- 1. Confirm that all inputs are connected to the correct terminals and are secure.
- 2. Verify that AC line power at the disconnect device is within the rated value of the drive.
- 3. Verify that any digital control power is 24 volts.
- 4. Verify that the Sink (SNK)/Source (SRC) Setup DIP switch is set to match your control wiring scheme. See [Figure 5](#) for location.

Important: The default control scheme is Source (SRC). The Stop terminal is jumpered (I/O Terminals 01 and 11) to allow starting from the keypad. If the control scheme is changed to Sink (SNK), the jumper must be removed from I/O Terminals 01 and 11 and installed between I/O Terminals 01 and 04.

- ❑ 5. Verify that the Stop input is present or the drive will not start.

Important: If I/O Terminal 01 is used as a stop input, the jumper between I/O Terminals 01 and 11 must be removed.

Applying Power to the Drive

- ❑ 6. Apply AC power and control voltages to the drive.
- ❑ 7. Familiarize yourself with the integral keypad features (see [Integral Keypad on page 34](#)) before setting any Program Group parameters.

Start, Stop, Direction, and Speed Control

Factory default parameter values allow the drive to be controlled from the integral keypad. No programming is required to start, stop, change direction and control speed directly from the integral keypad.

Important: To disable reverse operation, see [A434](#) [Reverse Disable].


If a fault appears on power up, see [Fault Descriptions on page 73](#) for an explanation of the fault code.

Variable Torque Fan/Pump Applications










For improved motor tuning performance when using a premium efficient motor on a variable torque load, set [A453](#) [Boost Select] to option 2 “35.0, VT”.

Integral Keypad

Menu	Description
<i>d</i>	Display Group (View Only) Consists of commonly viewed drive operating conditions.
<i>P</i>	Basic Program Group Consists of most commonly used programmable functions.
<i>t</i>	Terminal Block Group Consists of programmable functions for control terminals.
<i>C</i>	Communications Group Consists of programmable functions for communications.
<i>A</i>	Advanced Program Group Consists of remaining programmable functions.
<i>F</i>	Fault Designator Consists of list of codes for specific fault conditions. Displayed only when fault is present.















No.	LED	LED State	Description
❶	Run/Direction Status	Steady red	Indicates drive is running and commanded motor direction.
		Flashing red	Drive has been commanded to change direction. Indicates actual motor direction while decelerating to zero.
❷	Alphanumeric Display	Steady red	Indicates parameter number, parameter value, or fault code.
		Flashing red	Single digit flashing indicates that digit can be edited. All digits flashing indicates a fault condition.
❸	Displayed Units	Steady red	Indicates the units of the parameter value being displayed.
❹	Program Status	Steady red	Indicates parameter value can be changed.
❺	Fault Status	Flashing red	Indicates drive is faulted.
❻	Pot Status	Steady green	Indicates potentiometer on Integral Keypad is active.
❼	Start Key Status	Steady green	Indicates Start key on Integral Keypad is active. The Reverse key is also active unless disabled by A434 [Reverse Disable].

















No.	Key	Name	Description
❸		Escape	Back one step in programming menu. Cancel a change to a parameter value and exit Program Mode.
		Select	Advance one step in programming menu. Select a digit when viewing parameter value.
		Up Arrow	Scroll through groups and parameters. Increase/decrease the value of a flashing digit.
		Down Arrow	
❹		Enter	Advance one step in programming menu. Save a change to a parameter value.
		Speed Potentiometer	Used to control speed of drive. Default is active. Controlled by parameter P108 [Speed Reference].
		Start	Used to start the drive. Default is active. Controlled by parameter P106 [Start Source].
		Reverse	Used to reverse direction of the drive. Default is active. Controlled by parameters P106 [Start Source] and A434 [Reverse Disable].
		Stop	Used to stop the drive or clear a fault. This key is always active. Controlled by parameter P107 [Stop Mode].

Viewing and Editing Parameters

The last user-selected Display Group parameter is saved when power is removed and is displayed by default when power is reapplied.

The following is an example of basic integral keypad and display functions. This example provides basic navigation instructions and illustrates how to program the first Program Group parameter.

Step	Key(s)	Example Displays
<p>1. When power is applied, the last user-selected Display Group parameter number is briefly displayed with flashing characters. The display then defaults to that parameter's current value. (Example shows the value of d001 [Output Freq] with the drive stopped.)</p>		
<p>2. Press Esc once to display the Display Group parameter number shown on power-up. The parameter number will flash.</p>		
<p>3. Press Esc again to enter the group menu. The group menu letter will flash.</p>		
<p>4. Press the Up Arrow or Down Arrow to scroll through the group menu (d, P, t, C, and A).</p> <p>Press Enter or Sel to enter a group. The rightmost digit of the last viewed parameter in that group will flash.</p>	 or  or  or 	
<p>5. Press the Up Arrow or Down Arrow to scroll through the parameters in the group.</p>	 or 	

Step	Key(s)	Example Displays
6. Press Enter or Sel to view the value of a parameter. If you do not want to edit the value, press Esc to return to the parameter number.	 Or 	 <ul style="list-style-type: none"> ● VOLTS ○ AMPS ○ HERTZ
7. Press Enter or Sel to enter program mode to edit the parameter value. The rightmost digit will flash and the Program LED will illuminate if the parameter can be edited.	 Or 	 <ul style="list-style-type: none"> ● VOLTS ○ AMPS ○ HERTZ
8. Press the Up Arrow or Down Arrow to change the parameter value.	 <p style="text-align: center;">OR</p> 	
If desired, press Sel to move from digit to digit or bit to bit. The digit or bit that you can change will flash.		 <ul style="list-style-type: none"> ● VOLTS ○ AMPS ○ HERTZ
9. Press Esc to cancel a change. The digit will stop flashing, the previous value is restored and the Program LED will turn off.		 <ul style="list-style-type: none"> ● VOLTS ○ AMPS ○ HERTZ
Or Press Enter to save a change. The digit will stop flashing and the Program LED will turn off.		 <ul style="list-style-type: none"> ● VOLTS ○ AMPS ○ HERTZ
10. Press Esc to return to the parameter list. Continue to press Esc to back out of the programming menu. If pressing Esc does not change the display, then d001 [Output Frequency] is displayed. Press Enter or Sel to enter the group menu again.		 <ul style="list-style-type: none"> ○ VOLTS ○ AMPS ○ HERTZ

The Basic Program Group ([page 46](#)) contains the most commonly changed parameters.

Notes:

Programming and Parameters


Chapter 3 provides a complete listing and description of the PowerFlex 4M parameters. Parameters are programmed (viewed/edited) using the integral keypad. As an alternative, programming can also be performed using Connected Components Workbench software™ or DriveExecutive™ software, a personal computer, and a serial converter module. See [Appendix B](#) for catalog numbers.


About Parameters

To configure a drive to operate in a specific way, drive parameters may have to be set. Three types of parameters exist:






- **ENUM**
ENUM parameters allow a selection from 2 or more items. Each item is represented by a number.
- **Numeric Parameters**
These parameters have a single numerical value (such as 0.1 Volts).
- **Bit Parameters**
Bit parameters have four individual bits associated with features or conditions. If the bit is 0, the feature is off or the condition is false. If the bit is 1, the feature is on or the condition is true.

Some parameters are marked as follows.

 = Stop drive before changing this parameter.

 = 32-bit parameter. Parameters marked 32-bit will have two parameter numbers when using RS-485 communications and programming software.

Parameter Organization

Group	Parameters			
Basic Display 	Output Freq	d001	Control Source	d012
	Commanded Freq	d002	Contrl In Status	d013
	Output Current	d003	Dig In Status	d014
	Output Voltage	d004	Comm Status	d015
	DC Bus Voltage	d005	Control SW Ver	d016
	Drive Status	d006	Drive Type	d017
	Fault 1 Code	d007	Elapsed Run Time	d018
	Fault 2 Code	d008	Testpoint Data	d019
	Fault 3 Code	d009	Analog In 0-10V	d020
	Process Display	d010	Analog In 4-20mA	d021
			Drive Temp	d022
Basic Program 	Motor NP Volts	P101	Stop Mode	P107
	Motor NP Hertz	P102	Speed Reference	P108
	Motor OL Current	P103	Accel Time 1	P109
	Minimum Freq	P104	Decel Time 1	P110
	Maximum Freq	P105	Motor OL Ret	P111
	Start Source	P106	Reset To Defaults	P112
Terminal Block 	Digital In1 Sel	t201	Analog In 4-20mA Lo	d213
	Digital In2 Sel	t202	Analog In 4-20mA Hi	d214
	Analog In 0-10V Lo	t211	Relay Out Sel	t221
	Analog In 0-10V Hi	t212	Relay Out Level	t222
Communications 	Language	C301		
	Comm Data Rate	C302		
	Comm Node Addr	C303		
	Comm Loss Action	C304		
	Comm Loss Time	C305		
	Comm Format	C306		
	Comm Write Mode	C307		
Advanced Program 	Accel Time 2	A401	Compensation	A436
	Decel Time 2	A402	Slip Hertz @ FLA	A437
	S Curve %	A403	Process Time Lo	A438
	Jog Frequency	A404	Process Time Hi	A439
	Jog Accel/Decel	A405	Process Factor	A440
	Internal Freq	A409	Bus Reg Mode	A441
	Preset Freq 0	A410	Current Limit	A442
	Preset Freq 1	A411	Motor OL Select	A444
	Preset Freq 2	A412	PWM Frequency	A446
	Preset Freq 3	A413	SW Current Trip	A448
	Skip Frequency	A418	Fault Clear	A450
	Skip Freq Band	A419	Auto Rstrt Tries	A451
	DC Brake Time	A424	Auto Rstrt Delay	A452
	DC Brake Level	A425	Boost Select	A453
	DB Resistor Sel	A427	Maximum Voltage	A457
	DB Duty Cycle	A428	Program Lock	A458
	Start At PowerUp	A433	Testpoint Sel	A459
	Reverse Disable	A434	Motor NP FLA	A461
	Flying Start En	A435		

Display Group

d001 [Output Freq]

Related Parameters: [d002](#), [d010](#), [P104](#), [P105](#), [P108](#)

Output frequency present at T1, T2, and T3 (U, V, and W).

Values	Default	Read Only
	Min/Max:	0.0/ P105 [Maximum Freq]
	Display:	0.1 Hz

d002 [Commanded Freq]

Related Parameters: [d001](#), [d013](#), [P104](#), [P105](#), [P108](#)

Value of the active frequency command. Displays the commanded frequency even if the drive is not running.

Important: The frequency command can come from a number of sources. See [Start and Speed Reference Control on page 29](#) for details.

Values	Default	Read Only
	Min/Max:	0.0/ P105 [Maximum Freq]
	Display:	0.1 Hz

d003 [Output Current]

The output current present at T1, T2, and T3 (U, V, and W).

Values	Default	Read Only
	Min/Max:	0.00/(Drive Rated Amps × 2)
	Display:	0.01 Amps

d004 [Output Voltage]

Related Parameters: [P101](#), [A453](#), [A457](#)

Output voltage present at terminals T1, T2, and T3 (U, V, and W).

Values	Default	Read Only
	Min/Max:	0/Drive Rated Volts
	Display:	0.1 VAC

d005 [DC Bus Voltage]

Present DC bus voltage level.


Values	Default	Read Only
	Min/Max:	Based on Drive Rating
	Display:	1 VDC

Display Group *(continued)*

d006 [Drive Status]

Related Parameter: [A434](#)

Present operating condition of the drive.



Values	Default	Read Only
	Min/Max:	0/1
	Display:	1

d007 [Fault 1 Code]

d008 [Fault 2 Code]

d009 [Fault 3 Code]


A code that represents a drive fault. The codes will appear in these parameters in the order they occur ([d007](#) [Fault 1 Code] = the most recent fault). Repetitive faults will only be recorded once.

See [Chapter 4](#) for fault code descriptions.

Values	Default	Read Only
	Min/Max:	F2/F122
	Display:	F1

d010 [Process Display]

Related Parameters: [d001](#), [A440](#), [A438](#), [A439](#)

 32-bit parameter

The output frequency scaled by [A440](#) [Process Factor] or by [A438](#) [Process Time Lo] and [A439](#) [Process Time Hi].

$$\text{Output Freq} \times \text{Process Factor} = \text{Process Display}$$


Values	Default	Read Only
	Min/Max:	0.00/9999
	Display:	0.01 – 1

Display Group *(continued)*

d012 [Control Source]

Related Parameters: [P106](#), [P108](#), [I201](#), [I202](#)

Displays the active source of the Start Command and Speed Command which are normally defined by the settings of [P106](#) [Start Source] and [P108](#) [Speed Reference] but may be overridden by digital inputs. See the flowcharts on pages [page 29](#) and [page 30](#) for details.




Values	Default	Read Only
Min/Max:		0/9
Display:		1

d013 [Contrl In Status]

Related Parameters: [d002](#), [P104](#), [P105](#)

Status of the control terminal block control inputs.

Important: Actual control commands may come from a source other than the control terminal block.



⁽¹⁾ The stop input must be present in order to start the drive.
 When this bit is a 1 the drive can be started.
 When this bit is a 0 the drive will stop.


Values	Default	Read Only
Min/Max:		0/1
Display:		1

Display Group *(continued)*

d014 [Dig In Status]

Related Parameters: [t201](#), [t202](#)

Status of the control terminal block digital inputs.




Values	Default	Read Only
	Min/Max:	0/1
	Display:	1

d015 [Comm Status]

Related Parameters: [C302](#)...[C306](#)

Status of the communications ports.



Values	Default	Read Only
	Min/Max:	0/1
	Display:	1

d016 [Control SW Ver]

Main Control Board software version.

Values	Default	Read Only
	Min/Max:	1.00/99.99
	Display:	0.01

d017 [Drive Type]

Used by Rockwell Automation field service personnel.

Values	Default	Read Only
	Min/Max:	1001/9999
	Display:	1

Display Group *(continued)*

d018 [Elapsed Run Time]

Accumulated time drive is outputting power. Time is displayed in 10-hour increments.

Values	Default	Read Only
	Min/Max:	0/9999 Hrs
	Display:	1 (= 10 Hrs)

d019 [Testpoint Data]

Related Parameter: [A459](#)

The present value of the function selected in [A459](#) [Testpoint Sel].

Values	Default	Read Only
	Min/Max:	0/FFFF
	Display:	1 Hex

d020 [Analog In 0-10V]

Related Parameters: [I211](#), [I212](#)

The present value of the voltage at I/O Terminal 13 (100.0% = 10 volts).

Values	Default	Read Only
	Min/Max:	0.0/100.0%
	Display:	0.1%

d021 [Analog In 4-20mA]

Related Parameters: [I213](#), [I214](#)

The present value of the current at I/O Terminal 15 (0.0% = 4 mA, 100.0% = 20 mA).

Values	Default	Read Only
	Min/Max:	0.0/100.0%
	Display:	0.1%

d022 [Drive Temp]

Present operating temperature of the drive power section.

Values	Default	Read Only
	Min/Max:	0/120 °C
	Display:	1 °C

Basic Program Group

P101 [Motor NP Volts]

Related Parameters: [d004](#), [A453](#)



Stop drive before changing this parameter.

Set to the motor nameplate rated voltage.

Values	Default	Based on Drive Rating
	Min/Max:	20/Drive Rated Voltage
	Display:	1 VAC

P102 [Motor NP Hertz]

Related Parameters: [A453](#), [A444](#)



Stop drive before changing this parameter.

Set to the motor nameplate rated frequency.

Values	Default	60 Hz
	Min/Max:	10/400 Hz
	Display:	1 Hz

P103 [Motor OL Current]

Related Parameters: [P111](#), [t221](#), [A441](#), [A444](#), [A448](#), [A437](#)

Set to the maximum allowable motor current.

The drive faults on an F7 Motor Overload if the value of this parameter is exceeded by 150% for 60 seconds or 200% for 3 seconds.

Values	Default	Based on Drive Rating
	Min/Max:	0.0/(Drive Rated Amps × 2)
	Display:	0.1 Amps

P104 [Minimum Freq]

Related Parameters: [d001](#), [d002](#), [d013](#), [P105](#), [t211](#), [t213](#), [A438](#)

Sets the lowest frequency the drive outputs continuously

Values	Default	0.0 Hz
	Min/Max:	0.0/400.0 Hz
	Display:	0.1 Hz

P105 [Maximum Freq]

Related Parameters: [d001](#), [d002](#), [d013](#), [P104](#), [A404](#), [t212](#), [t214](#), [A438](#)



Stop drive before changing this parameter.

Sets the highest frequency the drive outputs

Values	Default	60 Hz
	Min/Max:	0/400 Hz
	Display:	1 Hz

Basic Program Group *(continued)*

P106 [Start Source]

Related Parameters: [d012](#), [P107](#)



Stop drive before changing this parameter.

Sets the control scheme used to start the drive

See [Start and Speed Reference Control on page 29](#) for details about how other drive settings can override the setting of this parameter.

Important: For all settings except option 3, the drive must receive a leading edge from the start input for the drive to start after a stop input, loss of power, or fault condition.

Options 0	“Keypad” (Default)	<ul style="list-style-type: none"> • Integral keypad controls drive operation • I/O Terminal 1 “Stop” = Coast-to-stop • When active, the Reverse key is also active unless disabled by A434 [Reverse Disable].
1	“3-Wire”	I/O Terminal 1 “Stop” = Stop according to the value set in P107 [Stop Mode].
2	“2-Wire”	I/O Terminal 1 “Stop” = Coast-to-stop
3	“2-W Lvl Sens”	Drive will restart after a “Stop” command when: <ul style="list-style-type: none"> • Stop is removed and • Start is held active



ATTENTION: Hazard of injury exists due to unintended operation. When P106 [Start Source] is set to option 3, and the Run input is maintained, the Run inputs do not need to be toggled after a Stop input for the drive to run again. A Stop function is provided only when the Stop input is active (open).

4	“2-W Hi Speed”	Important: There is greater potential voltage on the output terminals when using this option. <ul style="list-style-type: none"> • Outputs are kept in a ready-to-run state. The drive responds to a “Start” command within 10 ms. • I/O Terminal 1 “Stop” = Coast-to-stop
5	“Comm Port” ⁽¹⁾	<ul style="list-style-type: none"> • Remote communications. See Appendix C for details. • I/O Terminal 1 “Stop” = Coast-to-stop

⁽¹⁾ When using option 5 “Comm Port”, if the drive is using a network for control and the user’s program is maintaining a “Start” or “Jog” command without sending a “Stop command”, the drive will start automatically when power is cycled.

Basic Program Group *(continued)*

P107 [Stop Mode]

Related Parameters: [P106](#), [A418](#), [A425](#), [A427](#), [C304](#)

Active stop mode for all stop sources [for example, keypad, run forward (I/O Terminal 02), run reverse (I/O Terminal 03), RS-485 port] except as noted below.

Important: I/O Terminal 01 is always a coast-to-stop input except when [P106](#) [Start Source] is set for “3-Wire” control. When in three wire control, I/O Terminal 01 is controlled by [P107](#) [Stop Mode].

Options	0	“Ramp, CF” ⁽¹⁾ (Default)	Ramp to Stop. “Stop” command clears active fault.
	1	“Coast, CF” ⁽¹⁾	Coast-to-stop. “Stop” command clears active fault.
	2	“DC Brake, CF” ⁽¹⁾	DC Injection Braking Stop. “Stop” command clears active fault.
	3	“DCBrkAuto,CF” ⁽¹⁾	DC Injection Braking Stop with Auto Shutoff. <ul style="list-style-type: none"> • Standard DC Injection Braking for value set in A424 [DC Brake Time]. OR • Drive shuts off if the drive detects that the motor is stopped. “Stop” command clears active fault.
	4	“Ramp”	Ramp to Stop
	5	“Coast”	Coast-to-stop
	6	“DC Brake”	DC Injection Braking Stop
	7	“DC BrakeAuto”	DC Injection Braking Stop with Auto Shutoff. <ul style="list-style-type: none"> • Standard DC Injection Braking for value set in A424 [DC Brake Time]. OR • Drive shuts off if current limit is exceeded.

⁽¹⁾ Stop input also clears active fault.

Basic Program Group *(continued)*

P108 [Speed Reference]

Related Parameters: [d001](#), [d002](#), [d012](#), [P109](#), [P110](#), [i201](#), [i202](#), [A409](#), [A410...A413](#), [i211](#), [i212](#), [i213](#), [i214](#)

Sets the source of the speed reference to the drive.

The drive speed command can be obtained from a number of different sources. The source is normally determined by [P108](#) [Speed Reference]. However, when [i201...i202](#) [Digital Inx Sel] is set to option 2, 4, 5, 6, 11, 12, 13, 14 and the digital input is active, the speed reference commanded by [P108](#) [Speed Reference] will be overridden. See the flowchart on [page 29](#) for more information on speed reference control priority.

Options	0	“Drive Pot” (Default)	Internal frequency command from the potentiometer on the integral keypad
	1	“InternalFreq”	Internal frequency command from A409 [Internal Freq]
	2	“0-10V Input”	External frequency command from the 0...10V analog input or remote potentiometer
	3	“4-20mA Input”	External frequency command from the 4...20 mA analog input
	4	“Preset Freq”	External frequency command as defined by A410...A413 [Preset Freq x] when i201 and i202 [Digital Inx Sel] are programmed as “Preset Frequencies” and the digital inputs are active.
	5	“Comm Port”	External frequency command from the communications port


P109 [Accel Time 1]

Related Parameters: [P108](#), [P110](#), [i201](#), [i202](#), [A401](#), [A410...A413](#)

Sets the rate of acceleration for all speed increases.

$$\frac{\text{Maximum Freq}}{\text{Accel Time}} = \text{Accel Rate}$$

Values	Default	10.0 Secs
	Min/Max:	0.0/600.0 Secs
	Display:	0.1 Secs



Basic Program Group *(continued)*


P110 [Decel Time 1]

Related Parameters: [P108](#), [P109](#), [I201](#), [I202](#), [A402](#), [A410...A413](#)

Sets the rate of deceleration for all speed decreases.

$$\frac{\text{Maximum Freq}}{\text{Decel Time}} = \text{Decel Rate}$$

Values	Default	10.0 Secs
	Min/Max:	0.1/600.0 Secs
	Display:	0.1 Secs



P111 [Motor OL Ret]

Related Parameter: [P103](#)

Enables/disables the Motor Overload Retention function. When Enabled, the value held in the motor overload counter is saved at power-down and restored at power-up. A change to this parameter setting resets the counter.

Options	0 "Disabled" (Default)
	1 "Enabled"

P112 [Reset To Defaults]



Stop drive before changing this parameter.

Resets all parameter values to factory defaults.

Options	0 "Idle State" (Default)	
	1 "Reset Defaults"	<ul style="list-style-type: none"> After the reset function is complete, this parameter sets itself back to "0". Causes an F48 Params Defaulted fault.

Terminal Block Group

t201 [Digital In1 Sel]

(I/O Terminal 5)

Related Parameters: [d012](#), [d014](#), [P108](#), [P109](#), [P110](#), [t211](#)...[t214](#), [A401](#), [A402](#), [A404](#), [A405](#), [A410](#)...[A413](#)

t202 [Digital In2 Sel]

(I/O Terminal 6)



Stop drive before changing this parameter.

Selects the function for the digital inputs. See the flowchart on [page 29](#) for more information on speed reference control priority.

Options	0	“Not Used”	Terminal has no function but can be read over network communications via d014 [Dig In Status]
	1	“Acc 2 & Dec 2”	<ul style="list-style-type: none"> When active, A401 [Accel Time 2] and A402 [Decel Time 2] are used for all ramp rates except Jog. Can only be tied to one input <p>See the flowchart on page 30 for more information on Accel/Decel selection.</p>
	2	“Jog”	<ul style="list-style-type: none"> When input is present, drive accelerates according to the value set in A405 [Jog Accel/Decel] and ramps to the value set in A404 [Jog Frequency]. When input is removed, drive ramps to a stop according to the value set in A405 [Jog Accel/Decel]. A valid “Start” command overrides this input.
	3	“Aux Fault”	When enabled, an F2 Auxiliary Input fault occurs when the input is removed.
	4	“Preset Freq” (Default)	<p>See A410...A413 [Preset Freq x].</p> <p>Important: Digital Inputs have priority for frequency control when programmed as a Preset Speed and are active. See flowchart on page 29 for more information on speed reference control priority.</p>
	5	“Local”	When active, sets integral keypad as start source and potentiometer on the integral keypad as speed source.
	6	“Comm Port”	<ul style="list-style-type: none"> When active, sets communications device as default start/speed command source. Can only be tied to one input
	7	“Clear Fault”	When active, clears an active fault.
	8	“RampStop,CF”	Causes drive to immediately ramp to a stop regardless of how P107 [Stop Mode] is set.
	9	“CoastStop,CF”	Causes drive to immediately coast to a stop regardless of how P107 [Stop Mode] is set.
	10	“DCInjStop,CF”	Causes drive to immediately begin a DC Injection stop regardless of how P107 [Stop Mode] is set.
	11	“Jog Forward”	Drive accelerates to A404 [Jog Frequency] according to A405 [Jog Accel/Decel] and ramps to stop when input becomes inactive. A valid start overrides this command.
	12	“Jog Reverse”	Drive accelerates to A404 [Jog Frequency] according to A405 [Jog Accel/Decel] and ramps to stop when input becomes inactive. A valid start overrides this command.

t201 & t202 Options (Cont.)	13 "10V In Ctrl"	Selects 0...10V or ±10V control as the frequency reference. Start source is not changed.
	14 "20mA In Ctrl"	Selects 4...20 mA control as the frequency reference. Start source is not changed.
	15 "Anlg Invert"	Inverts the scaling of the analog input levels set in t211 [Anlg In 0-10V Lo] and t212 [Anlg In 0-10V Hi] or t213 [Anlg In4-20mA Lo] and t214 [Anlg In4-20mA Hi].
	16...27	Reserved


t211 [Anlg In 0-10V Lo]

Related Parameters: [d020](#), [P104](#), [P108](#), [t201](#), [t202](#)

Sets the analog input level that corresponds to [P104](#) [Minimum Freq] if a 0...10V input is used by [P108](#) [Speed Reference].

Analog inversion can be accomplished by setting this value larger than [t212](#) [Anlg In 0-10V Hi] or by setting [t201...t202](#) [Digital Inx Sel] to option 15 "Anlg Invert".

Values	Default	0.0%
	Min/Max:	0.0/100.0%
	Display:	0.1%



t212 [Anlg In 0-10V Hi]

Related Parameters: [d020](#), [P105](#), [P108](#), [t201](#), [t202](#)

Sets the analog input level that corresponds to [P105](#) [Maximum Freq] if a 0...10V input is used by [P108](#) [Speed Reference].

Analog inversion can be accomplished by setting this value smaller than [t211](#) [Anlg In 0-10V Lo] or by setting [t201...t202](#) [Digital Inx Sel] to option 15 "Anlg Invert".

Values	Default	100.0%
	Min/Max:	0.0/100.0%
	Display:	0.1%

t213 [Anlg In4-20mA Lo]

Related Parameters: [d021](#), [P104](#), [P108](#), [t201](#), [t202](#)

Sets the analog input level that corresponds to [P104](#) [Minimum Freq] if a 4...20 mA input is used by [P108](#) [Speed Reference].

Analog inversion can be accomplished by setting this value larger than [t214](#) [Anlg In4-20mA Hi] or by setting [t201...t202](#) [Digital Inx Sel] to option 15 "Anlg Invert".

Values	Default	0.0%
	Min/Max:	0.0/100.0%
	Display:	0.1%

Terminal Block Group *(continued)*

t214 [Anlg In4-20mA Hi]

Related Parameters: [d021](#), [P105](#), [P108](#), [t201](#), [t202](#)

Sets the analog input level that corresponds to [P105](#) [Maximum Freq] if a 4...20 mA input is used by [P108](#) [Speed Reference].

Analog inversion can be accomplished by setting this value smaller than [t213](#) [Anlg In4-20mA Lo] or by setting [t201](#)...[t202](#) [Digital Inx Sel] to option 15 "Anlg Invert".

Values	Default	100.0%
	Min/Max:	0.0/100.0%
	Display:	0.1%

t221 [Relay Out Sel]

Related Parameters: [P103](#), [t222](#), [A451](#)


Sets the condition that changes the state of the output relay contacts.

Options	0 "Ready/Fault" (Default)	Relay changes state when power is applied. This indicates that the drive is ready for operation. Relay returns drive to shelf state when power is removed or a fault occurs.
	1 "At Frequency"	Drive reaches commanded frequency.
	2 "MotorRunning"	Motor is receiving power from the drive.
	3 "Reverse"	Drive is commanded to run in reverse direction.
	4 "Motor Overld"	Motor overload condition exists
	5 "Ramp Reg"	Ramp regulator is modifying the programmed accel/decel times to avoid an overcurrent or overvoltage fault from occurring.
	6 "Above Freq"	Drive exceeds the frequency (Hz) value set in t222 [Relay Out Level].
	7 "Above Cur"	Drive exceeds the current (% Amps) value set in t222 [Relay Out Level]. Important: Value for t222 [Relay Out Level] must be entered in percent of drive rated output current.
	8 "Above DCVolt"	Drive exceeds the DC bus voltage value set in t222 [Relay Out Level].
	9 "Retries Exst"	Value set in A451 [Auto Rstrt Tries] is exceeded.
	10 "Above Anlg V"	<ul style="list-style-type: none"> Analog input voltage (I/O Terminal 13) exceeds the value set in t222 [Relay Out Level]. This parameter setting can also be used to indicate a PTC trip point when the input (I/O Terminal 13) is wired to a PTC and external resistor. Use t222 to set threshold.
	11 "ParamControl"	Enables the output to be controlled over network communications by writing to t222 [Relay Out Level]. (0 = Off, 1 = On.)
	12 "NonRec Fault"	<ul style="list-style-type: none"> Value set in A451 [Auto Rstrt Tries] is exceeded. A451 [Auto Rstrt Tries] is not enabled. A Non-resettable fault has occurred.
	13 "I/O Control"	Enables the output to be controlled by bit 6 of the logic command word. See Writing (06) Logic Command Data on page 102 for more information.
	14...22	Reserved

Terminal Block Group *(continued)*

t222 [Relay Out Level]

Related Parameter: [t221](#)

 32-bit parameter

Sets the trip point for the digital output relay if the value of [t221](#) [Relay Out Sel] is 6, 7, 8, 10, or 11.

t221 Setting	t222 Min/Max
6	0/400 Hz
7	0/180%
8	0/815 Volts
10	0/100%
11	0/1

Values	Default	0.0
	Min/Max:	As above
	Display:	0.1

Communications Group

C301 [Language]

Selects the language displayed by the remote communications option.

Options	1	“English” (Default)
	2	“Second Lang” (Reserved)

C302 [Comm Data Rate]

Related Parameter: [d015](#)

Sets the serial port rate for the RS-485 (DSI) port.

Important: Power to drive must be cycled before any changes affects drive operation.

Options	0	“1200”
	1	“2400”
	2	“4800”
	3	“9600” (Default)
	4	“19.2K”
	5	“38.4K”

C303 [Comm Node Addr]

Related Parameter: [d015](#)

Sets the drive node address for the RS-485 (DSI) port if using a network connection.

Important: Power to drive must be cycled before any changes affects drive operation.

Values	Default	100
	Min/Max:	1/247
	Display:	1

C304 [Comm Loss Action]

Related Parameters: [d015](#), [P107](#), [C305](#)

Selects the drive’s response to a loss of the communication connection or excessive communication errors.

Options	0	“Fault” (Default)	Drive will fault on an F81 Comm Loss and coast-to-stop.
	1	“Coast to Stop”	Stops drive via coast-to-stop.
	2	“Stop”	Stops drive via P107 [Stop Mode] setting.
	3	“Continu Last”	Drive continues operating at communication commanded speed saved in RAM.

Communications Group *(continued)*

C305 [Comm Loss Time]

Related Parameters: [d015](#), [C304](#)

Sets the time that the drive will remain in communication loss before implementing the option selected in [C304](#) [Comm Loss Action].

Values	Default	5.0 Secs
	Min/Max:	0.1/60.0 Secs
	Display:	0.1 Secs

C306 [Comm Format]

Selects the protocol (RTU only), data bits (8 data bits only), parity (None, Even, Odd), and stop bits (1 stop bit only) used by the RS-485 port on the drive.

See [Appendix C](#) for details on using the drive communication features.

Important: Power to drive must be cycled before any changes affects drive operation.

Options	0	"RTU 8-N-1" (Default)
	1	"RTU 8-E-1"
	2	"RTU 8-O-1"
	3	"RTU 8-N-2"
	4	"RTU 8-E-2"
	5	"RTU 8-O-2"

C307 [Comm Write Mode]

Determines whether parameter changes made over communication port are saved and stored in Non-volatile Storage (NVS) or RAM only. If they are stored in RAM, the values are lost at power-down.

Options	0	"Save" (Default)
	1	"RAM Only"



ATTENTION: Risk of equipment damage exists. If a controller is programmed to write parameter data to Non-volatile Storage (NVS) frequently, the NVS quickly exceeds its life cycle and cause the drive to malfunction. Do not create a program that frequently uses configurable outputs to write parameter data to NVS unless C307 [Comm Write Mode] is set to option 1.

Advanced Program Group


A401 [Accel Time 2]

Related Parameter: [P109](#)

When active, sets the rate of acceleration for all speed increases except jog. See the flowchart on [page 30](#) for details.

$$\frac{\text{Maximum Freq}}{\text{Accel Time}} = \text{Accel Rate}$$

Values	Default	20.0 Secs
	Min/Max:	0.0/600.0 Secs
	Display:	0.1 Secs




A402 [Decel Time 2]

Related Parameter: [P110](#)

When active, sets the rate of deceleration for all speed decreases except jog. See the flowchart on [page 30](#) for details.

$$\frac{\text{Maximum Freq}}{\text{Decel Time}} = \text{Decel Rate}$$

Values	Default	20.0 Secs
	Min/Max:	0.1/600.0 Secs
	Display:	0.1 Secs



Advanced Program Group *(continued)*


A403 [S Curve %]

Sets the percentage of acceleration or deceleration time that is applied to the ramp as S Curve. Time is added, 1/2 at the beginning and 1/2 at the end of the ramp.

Values	Default	0% (Disabled)
	Min/Max:	0/100%
	Display:	1%

Example:

Accel Time = 10 Seconds
 S Curve Setting = 50%
 S Curve Time = $10 \times 0.5 = 5$ Seconds
 Total Time = $10 + 5 = 15$ Seconds



A404 [Jog Frequency]

Related Parameters: [P105](#), [t201](#), [t202](#), [A405](#)

Sets the output frequency when a jog command is issued.

Values	Default	10.0 Hz
	Min/Max:	0.0/ P105 [Maximum Freq]
	Display:	0.1 Hz

A405 [Jog Accel/Decel]

Related Parameters: [t201](#), [t202](#), [A404](#)

Sets the acceleration and deceleration time when a jog command is issued.

Values	Default	10.0 Secs
	Min/Max:	0.1/600.0 Secs
	Display:	0.1 Secs

A409 [Internal Freq]

Related Parameter: [P108](#)

Provides the frequency command to the drive when [P108](#) [Speed Reference] is set to 1 "Internal Freq". When enabled, this parameter changes the frequency command in "real time" using the integral keypad Up Arrow or Down Arrow when in program mode.

Important: Once the desired command frequency is reached, the Enter key must be pressed to store this value to EEPROM memory. If the ESC key is used before the Enter key, the frequency returns to the original value following the normal accel/decel curve.

Values	Default	60.0 Hz
	Min/Max:	0.0/400.0 Hz
	Display:	0.1 Hz

Advanced Program Group *(continued)*

A410 [Preset Freq 0]⁽¹⁾

Related Parameters: [P108](#), [P109](#), [P110](#), [t201](#), [t202](#),
[A401](#), [A402](#)

A411 [Preset Freq 1]

A412 [Preset Freq 2]

A413 [Preset Freq 3]

Values	A410 Default	0.0 Hz
	A411 Default	5.0 Hz
	A412 Default	10.0 Hz
	A413 Default	20.0 Hz
	Min/Max:	0.0/400.0 Hz
	Display:	0.1 Hz

Provides a fixed frequency command value when [t201](#)...[t202](#) [Digital Inx Sell] is set to 4 "Preset Frequencies".

An active preset input will override speed command as shown in the flowchart on [page 30](#).

⁽¹⁾ To activate [A410](#) [Preset Freq 0] set [P108](#) [Speed Reference] to option 4 "Preset Freq 0-3".

Input State of Digital In 1 (I/O Terminal 05)	Input State of Digital In 2 (I/O Terminal 06)	Frequency Source	Accel / Decel Parameter Used ⁽²⁾
0	0	A410 [Preset Freq 0]	[Accel Time 1] / [Decel Time 1]
1	0	A411 [Preset Freq 1]	[Accel Time 1] / [Decel Time 1]
0	1	A412 [Preset Freq 2]	[Accel Time 2] / [Decel Time 2]
1	1	A413 [Preset Freq 3]	[Accel Time 2] / [Decel Time 2]

⁽²⁾ When a Digital Input is set to "Accel 2 & Decel 2", and the input is active, that input overrides the settings in this table.

A418 [Skip Frequency]

Related Parameter: [A419](#)

Sets the frequency at which the drive will not operate.

A setting of 0 disables this parameter.

Values	Default	0 Hz
	Min/Max:	0/400 Hz
	Display:	1 Hz

Advanced Program Group *(continued)*


A419 [Skip Freq Band]

Related Parameter: [A418](#)

Determines the bandwidth around [A418](#) [Skip Frequency]. A419 [Skip Freq Band] is applied above and below the actual skip frequency. See the diagram below.

A setting of 0.0 disables this parameter.

Values	Default:	0.0 Hz
	Min/Max:	0.0/30.0 Hz
	Display:	0.1 Hz



A424 [DC Brake Time]

Related Parameters: [P107](#), [A425](#)

Sets the length of time that DC brake current is "injected" into the motor. See parameter [A425](#) [DC Brake Level].

Values	Default	0.0 Secs
	Min/Max:	0.0/99.9 Secs (A setting of 99.9 = Continuous)
	Display:	0.1 Secs


Advanced Program Group *(continued)*

A425 [DC Brake Level]

Related Parameters: [P107](#), [A418](#)

Defines the maximum DC brake current, in amps, applied to the motor when [P107](#) [Stop Mode] is set to either “Ramp” or “DC Brake”.

Values	Default	Drive Rated Amps × 0.05
	Min/Max:	0.0/(Drive Rated Amps × 1.8)
	Display:	0.1 Amps



ATTENTION: If a hazard of injury due to movement of equipment or material exists, an auxiliary mechanical braking device must be used.



ATTENTION: This feature should not be used with synchronous or permanent magnet motors. Motors may be demagnetized during braking.

A427 [DB Resistor Sel]

Related Parameter: [A428](#)



Stop drive before changing this parameter.

Enables/disables external dynamic braking. This parameter applies only to Frame C drives.

Setting	Min/Max
0	“Disabled”
1	“Normal RA Res” (5% Duty Cycle) - See Table 16 on page 86
2	“No Protection” (100% Duty Cycle)
3	“% Duty Cycle” Limited (1% – 99% of Duty Cycle) - see A428

The drive is able to provide full braking indefinitely. Braking power is limited by the external DB resistor. When this parameter is set to 1 “Normal RA Res” and an appropriate RA resistor is used (see selection [Table 16](#)), the drive provides calculated resistor overload protection. However, the drive cannot protect against a brake IGBT failure.



ATTENTION: A risk of fire exists if external braking resistors are not protected. The external resistor package must be self-protected from over temperature or the protective circuit shown in [Figure 9 on page 91](#), or equivalent, must be supplied.

Values	Default	0
	Min/Max:	0/3
	Display:	1

Advanced Program Group *(continued)*

A428 [DB Duty Cycle]

Related Parameter: [A427](#)



Stop drive before changing this parameter.

Selects the duty cycle allowed for an external dynamic braking resistor when [A427](#) [DB Resistor Sel] is set to 3. This parameter applies only to Frame C drives.

Values	Default	5%
	Min/Max:	1/99%
	Display:	1%

A433 [Start At PowerUp]



Stop drive before changing this parameter.

Enables/disables a feature that allows a Start or Run command to automatically cause the drive to resume running at commanded speed after drive input power is restored. Requires a digital input configured for Run or Start and a valid start contact.



ATTENTION: Equipment damage and/or personal injury may result if this parameter is used in an inappropriate application. Do not use this function without considering applicable local, national and international codes, standards, regulations or industry guidelines.

Options	0	“Disabled” (Default)
	1	“Enabled”

A434 [Reverse Disable]

Related Parameter: [d006](#)



Stop drive before changing this parameter.

Enables/disables the function that allows the direction of motor rotation to be changed. The reverse command may come from a digital command, the keypad or a serial command. All reverse inputs including two-wire Run Reverse is ignored with reverse disabled.

Options	0	“Rev Enabled” (Default)
	1	“Rev Disabled”

A435 [Flying Start En]

Sets the condition that allows the drive to reconnect to a spinning motor at actual RPM.

Options	0	“Disabled” (Default)
	1	“Enabled”

Advanced Program Group *(continued)*

A436 [Compensation]

Enables/disables correction options that may improve problems with motor instability.

Options	0	“Disabled”	
	1	“Electrical” (Default)	Some drive/motor combinations have inherent instabilities which are exhibited as non-sinusoidal motor currents. This setting attempts to correct this condition.
	2	“Mechanical”	Some motor/load combinations have mechanical resonances which can be excited by the drive current regulator. This setting slows down the current regulator response and attempts to correct this condition.
	3	“Both”	

A437 [Slip Hertz @ FLA]

Related Parameter: [P103](#)

Compensates for the inherent slip in an induction motor. This frequency is added to the commanded output frequency based on motor current.

Values	Default	2.0 Hz
	Min/Max:	0.0/10.0 Hz
	Display:	0.1 Hz

A438 [Process Time Lo]

Related Parameters: [d010](#), [P104](#)

Scales the time value when the drive is running at [P104](#) [Minimum Freq]. When set to a value other than zero, [d010](#) [Process Display] indicates the duration of the process.

Values	Default	0.00
	Min/Max:	0.00/99.99
	Display:	0.01

A439 [Process Time Hi]

Related Parameters: [d010](#), [P105](#)

Scales the time value when the drive is running at [P105](#) [Maximum Freq]. When set to a value other than zero, [d010](#) [Process Display] indicates the duration of the process.

Values	Default	0.00
	Min/Max:	0.00/99.99
	Display:	0.01

Advanced Program Group *(continued)*

A440 [Process Factor]

Related Parameter: [d010](#)

Scales the value displayed by [d010](#) [Process Display].

$$\text{Output Freq} \times \text{Process Factor} = \text{Process Display}$$

Values	Default	30.0
	Min/Max:	0.1/999.9
	Display:	0.1

A441 [Bus Reg Mode]

Controls the operation of the drive voltage regulation, which is normally operational at deceleration or when the bus voltage rises.

See the Attention statement on [page 9](#) for important information on bus regulation.

Values	0	“Disabled”
	1	“Enabled” (Default)

A442 [Current Limit]

Maximum output current allowed before current limiting occurs.




Values	Default	Drive Rated Amps × 1.5
	Min/Max:	0.1/(Drive Rated Amps × 1.8)
	Display:	0.1 Amps

A444 [Motor OL Select]

Related Parameters: [P102](#), [P103](#)

Drive provides Class 10 motor overload protection. Settings 0...2 select the derating factor for the I²t overload function.

Options	0	“No Derate” (Default)
	1	“Min Derate”
	2	“Max Derate”




Advanced Program Group *(continued)*

A446 [PWM Frequency]

Sets the carrier frequency for the PWM output waveform. The chart below provides derating guidelines based on the PWM frequency setting.

Important: Ignoring derating guidelines can cause reduced drive performance.

Values	Default	4.0 kHz
	Min/Max:	2.0/10.0 kHz
	Display:	0.1 kHz



A448 [SW Current Trip]

Related Parameter: [P103](#)

Enables/disables a software instantaneous (within 100 ms) current trip.

Values	Default	0.0 (Disabled)
	Min/Max:	0.0/(Drive Rated Amps × 2)
	Display:	0.1 Amps

Advanced Program Group *(continued)*

A450 [Fault Clear]



Stop drive before changing this parameter.

Resets a fault and clears the fault queue. Used primarily to clear a fault over network communications.

Options	0	“Ready/Idle” (Default)
	1	“Reset Fault”
	2	“Clear Buffer” (Parameters d007...d009 [Fault x Code])

A451 [Auto Rstrt Tries]

Sets the maximum number of times the drive attempts to reset a fault and restart.

Clear a Type 1 fault and restart the drive.

1. Set [A451](#) [Auto Rstrt Tries] to a value other than “0”.
2. Set [A452](#) [Auto Rstrt Delay] to a value other than “0”.

Clear an OverVoltage, UnderVoltage or Heatsink OvrTmp fault without restarting the drive.

1. Set [A451](#) [Auto Rstrt Tries] to a value other than “0”.
2. Set [A452](#) [Auto Rstrt Delay] to “0”.



ATTENTION: Equipment damage and/or personal injury may result if this parameter is used in an inappropriate application. Do not use this function without considering applicable local, national and international codes, standards, regulations or industry guidelines.

Values	Default	0
	Min/Max:	0/9
	Display:	1

A452 [Auto Rstrt Delay]

Related Parameter: [A451](#)

Sets the time between restart attempts when [A451](#) [Auto Rstrt Tries] is set to a value other than zero.

Values	Default	1.0 Secs
	Min/Max:	0.0/120.0 Secs
	Display:	0.1 Secs

Advanced Program Group *(continued)*


A453 [Boost Select]

Related Parameters: [d004](#), [P101](#), [P102](#)

Sets the boost voltage (% of [P101](#) [Motor NP Volts]) and redefines the Volts per Hz curve.⁽¹⁾

⁽¹⁾ Drive may add additional voltage unless option 5 is selected.

Options		
1	"30.0, VT"	Variable Torque
2	"35.0, VT"	
3	"40.0, VT"	
4	"45.0, VT"	
5	"0.0 no IR"	
6	"0.0"	Constant Torque
7	"2.5, CT" [Default for 3.7, 5.5, 7.5 & 11.0 kW (5.0, 7.5, 10.0 & 15.0 HP) Drives]	
8	"5.0, CT" (Default)	
9	"7.5, CT"	
10	"10.0, CT"	
11	"12.5, CT"	
12	"15.0, CT"	
13	"17.5, CT"	
14	"20.0, CT"	



Advanced Program Group *(continued)*

A457 [Maximum Voltage]

Sets the highest voltage the drive will output.

Values	Default	Drive Rated Volts
	Min/Max:	20/Drive Rated Volts
	Display:	1 VAC

A458 [Program Lock]

Protects parameters against change by unauthorized personnel.

Options	0	“Unlocked” (Default)
	1	“Locked”

A459 [Testpoint Sel]

Used by Rockwell Automation field service personnel.

Values	Default	400
	Min/Max:	0/FFFF
	Display:	1 Hex

A461 [Motor NP FLA]

Set to the motor nameplate rated full load amps.

Values	Default	Drive Rated Amps
	Min/Max:	0.1/(Drive Rated Amps × 2)
	Display:	0.1 Amps

Parameter Cross Reference – by Name

Parameter Name	Number	Group	Page	Parameter Name	Number	Group	Page
Accel Time 1	P109	Basic Program	49	Flying Start En	A435	Advanced Program	62
Accel Time 2	A401	Advanced Program	57	Internal Freq	A409	Advanced Program	58
Analog In 0-10V	d020	Display	45	Jog Accel/Decel	A405	Advanced Program	58
Analog In 4-20mA	d021	Display	45	Jog Frequency	A404	Advanced Program	58
Anlg In 0-10V Hi	t212	Terminal Block	52	Language	C301	Communications	55
Anlg In 0-10V Lo	t211	Terminal Block	52	Maximum Freq	P105	Basic Program	46
Anlg In4-20mA Hi	t214	Terminal Block	53	Maximum Voltage	A457	Advanced Program	68
Anlg In4-20mA Lo	t213	Terminal Block	52	Minimum Freq	P104	Basic Program	46
Auto Rstrt Delay	A452	Advanced Program	66	Motor NP FLA	A461	Advanced Program	68
Auto Rstrt Tries	A451	Advanced Program	66	Motor NP Hertz	P102	Basic Program	46
Boost Select	A453	Advanced Program	67	Motor NP Volts	P101	Basic Program	46
Bus Reg Mode	A441	Advanced Program	64	Motor OL Current	P103	Basic Program	46
Comm Data Rate	C302	Communications	55	Motor OL Ret	P111	Basic Program	50
Comm Format	C306	Communications	56	Motor OL Select	A444	Advanced Program	64
Comm Loss Action	C304	Communications	55	Output Current	d003	Display	41
Comm Loss Time	C305	Communications	56	Output Freq	d001	Display	41
Comm Node Addr	C303	Communications	55	Output Voltage	d004	Display	41
Comm Status	d015	Display	44	Preset Freq 0	A410	Advanced Program	59
Comm Write Mode	C307	Communications	56	Preset Freq 1	A411	Advanced Program	59
Commanded Freq	d002	Display	41	Preset Freq 2	A412	Advanced Program	59
Compensation	A436	Advanced Program	63	Preset Freq 3	A413	Advanced Program	59
Contrl In Status	d013	Display	43	Process Display	d010	Display	42
Control Source	d012	Display	43	Process Factor	A440	Advanced Program	64
Control SW Ver	d016	Display	44	Process Time Hi	A439	Advanced Program	63
Current Limit	A441	Advanced Program	64	Process Time Lo	A438	Advanced Program	63
DB Duty Cycle	A428	Advanced Program	62	Program Lock	A458	Advanced Program	68
DB Resistor Sel	A427	Advanced Program	61	PWM Frequency	A446	Advanced Program	65
DC Brake Level	A425	Advanced Program	61	Relay Out Level	t222	Terminal Block	54
DC Brake Time	A424	Advanced Program	59	Relay Out Sel	t221	Terminal Block	53
DC Bus Voltage	d005	Display	41	Reset To Defaults	P112	Basic Program	50
Decel Time 1	P110	Basic Program	50	Reverse Disable	A434	Advanced Program	62
Decel Time 2	A402	Advanced Program	57	S Curve %	A403	Advanced Program	58
Dig In Status	d014	Display	44	Skip Freq Band	A419	Advanced Program	60
Digital In1 Sel	t201	Terminal Block	51	Skip Frequency	A418	Advanced Program	59
Digital In2 Sel	t202	Terminal Block	51	Slip Hertz @ FLA	A437	Advanced Program	63
Drive Status	d006	Display	42	Speed Reference	P108	Basic Program	49
Drive Temp	d022	Display	45	Start At PowerUp	A433	Advanced Program	62
Drive Type	d017	Display	44	Start Source	P106	Basic Program	47
Elapsed Run Time	d018	Display	45	Stop Mode	P107	Basic Program	48
Fault 1 Code	d007	Display	42	SW Current Trip	A448	Advanced Program	65
Fault 2 Code	d008	Display	42	Testpoint Data	d019	Display	45
Fault 3 Code	d009	Display	42	Testpoint Sel	A459	Advanced Program	68
Fault Clear	A450	Advanced Program	66				

Notes:

Troubleshooting

Chapter 4 provides information to guide you in troubleshooting the PowerFlex 4M drive. Included is a listing and description of drive faults (with possible solutions, when applicable).

Drive Status

The condition or state of your drive is constantly monitored. Any changes will be indicated through the integral keypad.

LED Indications


See [Integral Keypad on page 34](#) for information on drive status indicators and controls.

Faults


A fault is a condition that stops the drive. There are two fault types.

Type	Fault Description
①	Auto-reset/Run When this type of fault occurs, and A451 [Auto Rstrt Tries] is set to a value greater than "0," a user-configurable timer, A452 [Auto Rstrt Delay], begins. When the timer reaches zero, the drive attempts to automatically reset the fault. If the condition that caused the fault is no longer present, the fault will be reset and the drive will be restarted.
②	Non-resetable This type of fault may require drive or motor repair, or is caused by wiring or programing errors. The cause of the fault must be corrected before the fault can be cleared.

Fault Indication

Condition	Display
<p>Drive is indicating a fault.</p> <p>The integral keypad provides visual notification of a fault condition by displaying the following.</p> <ul style="list-style-type: none"> Flashing fault number Flashing fault indicator <p>Press the Escape key to regain control of the integral keypad.</p>	

Manually Clearing Faults

Step	Key(s)
<ol style="list-style-type: none"> Press Esc to acknowledge the fault. The fault information will be removed so that you can use the integral keypad. Access d007 Fault 1 Code to view the most recent fault information. Address the condition that caused the fault. The cause must be corrected before the fault can be cleared. See Figure 11. After corrective action has been taken, clear the fault by one of these methods. <ul style="list-style-type: none"> Press Stop if P107 [Stop Mode] is set to a value between "0" and "3". Cycle drive power. Set A450 [Fault Clear] to "1" or "2". Cycle digital input if t201...t202 [Digital Inx Select] is set to option 7 "Clear Fault". 	

Automatically Clearing Faults

Option / Step
<p>Clear a Type 1 fault and restart the drive.</p> <ol style="list-style-type: none"> Set A451 [Auto Rstrt Tries] to a value other than "0". Set A452 [Auto Rstrt Delay] to a value other than "0". <p>Clear an OverVoltage, UnderVoltage, or Heatsink OvrTmp fault without restarting the drive.</p> <ol style="list-style-type: none"> Set A451 [Auto Rstrt Tries] to a value other than "0". Set A452 [Auto Rstrt Delay] to "0".

Auto Restart (Reset/Run)

The Auto Restart feature provides the ability for the drive to automatically perform a fault reset followed by a start attempt without user or application intervention. This allows remote or "unattended" operation. Only certain faults are allowed to be reset. Certain faults (Type 2) that indicate possible drive component malfunction are not resettable.

Caution should be used when enabling this feature, since the drive will attempt to issue its own start command based on user selected programming.

Fault Descriptions

Table 11 – Fault Types, Descriptions, and Actions

No.	Fault	Type ⁽¹⁾	Description	Action
F2	Auxiliary Input	①	Auxiliary input interlock is open.	<ol style="list-style-type: none"> 1. Check remote wiring. 2. Verify communications programming for intentional fault.
F3	Power Loss	②	Excessive DC Bus voltage ripple.	<ol style="list-style-type: none"> 1. Monitor the incoming line for phase loss or line imbalance. 2. Check input line fuse.
F4	UnderVoltage	①	DC bus voltage fell below the minimum value.	Monitor the incoming AC line for low voltage or line power interruption.
F5	OverVoltage	①	DC bus voltage exceeded maximum value.	Monitor the AC line for high line voltage or transient conditions. Bus overvoltage can also be caused by motor regeneration. Extend the decel time or install dynamic brake option.
F6	Motor Stalled	①	Drive is unable to accelerate motor.	Increase P109 and/or A402 [Accel Time x] or reduce load so drive output current does not exceed the current set by parameter A441 [Current Limit].
F7	Motor Overload	①	Internal electronic overload trip.	<ol style="list-style-type: none"> 1. An excessive motor load exists. Reduce load so drive output current does not exceed the current set by parameter P103 [Motor OL Current]. 2. Verify A453 [Boost Select] setting
F8	Heatsink OvrTmp	①	Heatsink temperature exceeds a predefined value.	<ol style="list-style-type: none"> 1. Check for blocked or dirty heat sink fins. Verify that ambient temperature has not exceeded 40 °C (104 °F) for IP 30/NEMA 1/ UL Type 1 installations or 50 °C (122 °F) for IP20/Open type installations. 2. Check fan.
F12	HW OverCurrent	②	The drive output current has exceeded the hardware current limit.	Check programming. Check for excess load, improper A453 [Boost Select] setting, DC brake volts set too high or other causes of excess current.
F13	Ground Fault	②	A current path to earth ground has been detected at one or more of the drive output terminals.	Check the motor and external wiring to the drive output terminals for a grounded condition.

⁽¹⁾ See [page 71](#) for a description of fault types.

Chapter 4 Troubleshooting

No.	Fault	Type ⁽¹⁾	Description	Action
F38	Auto Rstrt Tries	②	Drive unsuccessfully attempted to reset a fault and resume running for the programmed number of A451 [Auto Rstrt Tries].	Correct the cause of the fault and manually clear.
F38	Phase U to Gnd	②	A phase to ground fault has been detected between the drive and motor in this phase.	<ol style="list-style-type: none"> 1. Check the wiring between the drive and motor. 2. Check motor for grounded phase. 3. Replace drive if fault cannot be cleared.
F39	Phase V to Gnd			
F40	Phase W to Gnd			
F41	Phase UV Short	②	Excessive current has been detected between these two output terminals.	<ol style="list-style-type: none"> 1. Check the motor and drive output terminal wiring for a shorted condition. 2. Replace drive if fault cannot be cleared.
F42	Phase UW Short			
F43	Phase VW Short			
F48	Params Defaulted		The drive was commanded to write default values to EEPROM.	<ol style="list-style-type: none"> 1. Clear the fault or cycle power to the drive. 2. Program the drive parameters as needed.
F63	SW OverCurrent	①	Programmed A448 [SW Current Trip] has been exceeded.	Check load requirements and A448 [SW Current Trip] setting.
F64	Drive Overload	②	Drive rating of 150% for 1 minute or 200% for 3 seconds has been exceeded.	Reduce load or extend Accel Time.
F70	Power Unit	②	Failure has been detected in the drive power section.	<ol style="list-style-type: none"> 1. Cycle power. 2. Replace drive if fault cannot be cleared.
F71	Net Loss		The communication network has faulted.	<ol style="list-style-type: none"> 1. Cycle power. 2. Check communications cabling. 3. Check network adapter setting. 4. Check external network status.
F81	Comm Loss	②	RS-485 (DSI) port stopped communicating.	<ol style="list-style-type: none"> 1. If adapter was not intentionally disconnected, check wiring to the port. Replace wiring, port expander, adapters or complete drive as required. 2. Check connection. 3. An adapter was intentionally disconnected. 4. Turn off using C304 [Comm Loss Action].
F100	Parameter Checksum	②	The checksum read from the board does not match the checksum calculated.	Set P112 [Reset To Defaults] to option 1 "Reset Defaults".
F122	I/O Board Fail	②	Failure has been detected in the drive control and I/O section.	<ol style="list-style-type: none"> 1. Cycle power. 2. Replace drive if fault cannot be cleared.

⁽¹⁾ See [page 71](#) for a description of fault types.

Common Symptoms and Corrective Actions

Motor does not Start.

Cause(s)	Indication	Corrective Action
No output voltage to the motor.	None	<p>Check the power circuit.</p> <ul style="list-style-type: none"> • Check the supply voltage. • Check all fuses and disconnects. <p>Check the motor.</p> <ul style="list-style-type: none"> • Verify that the motor is connected properly. <p>Check the control input signals.</p> <ul style="list-style-type: none"> • Verify that a Start signal is present. If 2-wire control is used, verify that either the Run Forward or Run Reverse signal is active, but not both. • Verify that I/O Terminal 01 is active. • Verify that P106 [Start Source] matches your configuration. • Verify that A434 [Reverse Disable] is not prohibiting movement.
Improper boost setting at initial start-up.	None	Set A453 [Boost Select] to option 2 "35.0, VT".
Drive is Faulted	Flashing red status light	<p>Clear fault.</p> <ul style="list-style-type: none"> • Press Stop • Cycle power • Set A450 [Fault Clear] to option 1 "Clear Faults". • Cycle digital input if I201...I202 [Digital Inx Sel] is set to option 7 "Clear Fault".

Drive does not Start from Integral Keypad.

Cause(s)	Indication	Corrective Action
Integral keypad is not enabled.	Green LED above Start key is not illuminated.	<ul style="list-style-type: none"> • Set parameter P106 [Start Source] to option 0 "Keypad". • Set parameter I201...I202 [Digital Inx Select] to option 5 "Local" and activate the input.
I/O Terminal 01 "Stop" input is not present.	None	Wire inputs correctly and/or install jumper.

Drive does not Start from Start or Run Inputs wired to the terminal block.

Cause(s)	Indication	Corrective Action
Drive is Faulted	Flashing red status light	<p>Clear fault.</p> <ul style="list-style-type: none"> • Press Stop • Cycle power • Set A450 [Fault Clear] to option 1 "Clear Faults". • Cycle digital input if t201...t202 [Digital Inx Select] is set to option 7 "Clear Fault".
<p>Incorrect programming.</p> <ul style="list-style-type: none"> • P106 [Start Source] is set to option 0 "Keypad" or option 5 "RS485 (DSI) Port". • t201...t202 [Digital Inx Select] is set to option 5 "Local" and the input is active. 	None	Check parameter settings.
<p>Incorrect input wiring. See page 25 for wiring examples.</p> <ul style="list-style-type: none"> • 2-wire control requires Run Forward, Run Reverse or Jog input. • 3-wire control requires Start and Stop inputs • Stop input is always required. 	None	Wire inputs correctly and/or install jumper.
Incorrect Sink/Source DIP switch setting.	None	Set switch to match wiring scheme.

Drive does not respond to changes in speed command.

Cause(s)	Indication	Corrective Action
No value is coming from the source of the command.	The drive "Run" indicator is lit and output is 0 Hz.	<ul style="list-style-type: none"> • Check d012 [Control Source] for correct source. • If the source is an analog input, check wiring and use a meter to check for presence of signal. • Check d002 [Commanded Freq] to verify correct command.
Incorrect reference source is being selected via remote device or digital inputs.	None	<ul style="list-style-type: none"> • Check d012 [Control Source] for correct source. • Check d014 [Dig In Status] to see if inputs are selecting an alternate source. Verify settings for t201...t202 [Digital Inx Select]. • Check P108 [Speed Reference] for the source of the speed reference. Reprogram as necessary. • Review the Speed Reference Control chart on page 29.

Motor and/or drive will not accelerate to commanded speed.

Cause(s)	Indication	Corrective Action
Acceleration time is excessive.	None	Reprogram P109 [Accel Time 1] or A401 [Accel Time 2].
Excess load or short acceleration times force the drive into current limit, slowing or stopping acceleration.	None	Compare d003 [Output Current] with A441 [Current Limit]. Remove excess load or reprogram P109 [Accel Time 1] or A401 [Accel Time 2]. Check for improper A453 [Boost Select] setting.
Speed command source or value is not as expected.	None	Verify d002 [Commanded Freq]. Check d012 [Control Source] for the proper Speed Command.
Programming is preventing the drive output from exceeding limiting values.	None	Check P105 [Maximum Freq] to insure that speed is not limited by programming.

Motor operation is unstable.

Cause(s)	Indication	Corrective Action
Motor data was incorrectly entered.	None	<ol style="list-style-type: none"> 1. Correctly enter motor nameplate data into P101, P102, and P103. 2. Enable A436 [Compensation]. 3. Use A453 [Boost Select] to reduce boost level.

Drive will not reverse motor direction.

Cause(s)	Indication	Corrective Action
Digital input is not selected for reversing control.	None	Check [Digital Inx Sel] See page 51 . Choose correct input and program for reversing mode.
Digital input is incorrectly wired.	None	Check input wiring. See page 24 .
Motor wiring is improperly phased for reverse.	None	Switch two motor leads.
Reverse is disabled.	None	Check A434 [Reverse Disable].

Drive does not power up.

Cause(s)	Indication	Corrective Action
No input power to drive.	None	Check the power circuit. <ul style="list-style-type: none"> • Check the supply voltage. • Check all fuses and disconnects.
Jumper between I/O Terminals P2 and P1 not installed and/or DC Bus Inductor not connected.	None	Install jumper or connect DC Bus Inductor.

Notes:

Supplemental Drive Information

Drive, Fuse & Circuit Breaker Ratings

The tables on the following pages provide recommended AC line input fuse and circuit breaker information. See Fusing and Circuit Breakers below for UL and IEC requirements. Sizes listed are the recommended sizes based on 40 °C (104 °F) and the U.S. N.E.C. Other country, state, or local codes may require different ratings.

Fusing

The recommended fuse types are listed below. If available current ratings do not match those listed in the tables provided, choose the next higher fuse rating.

- IEC – BS88 (British Standard) Parts 1 & 2⁽¹⁾, EN60269-1, Parts 1 & 2, type gG or equivalent should be used.
- UL – UL Class RK1, T, or J must be used.⁽²⁾

Circuit Breakers

The “non-fuse” listings in the following tables include inverse time circuit breakers, instantaneous trip circuit breakers (motor circuit protectors) and 140M/140MT self-protected combination motor controllers. If one of these is chosen as the desired protection method, the following requirements apply:

- IEC – Both types of circuit breakers and 140M/140MT self-protected combination motor controllers are acceptable for IEC installations.
- UL – Only inverse time circuit breakers and the specified 140M/140MT self-protected combination motor controllers are acceptable for UL installations.

(1) Typical designations include, but may not be limited to the following; Parts 1 & 2: AC, AD, BC, BD, CD, DD, ED, EFS, EF, FF, FG, GF, GG, GH.

(2) Typical designations include; Type J - JKS, LPJ, DFJ
Type T - JJS, JJN
Type RK1 - LPS, KTS, KTN

Specifications

Table 12 – Drive Ratings






Catalog Number	Output Ratings		Input Ratings				Branch Circuit Protection				DC Fuse ⁽⁵⁾	
	kW (HP)	Amps	Voltage Range	kVA	Amps	Fuses	140M/140MT Motor Protectors ⁽²⁾⁽³⁾	Contactors	Min. Enclosure Volume ⁽⁴⁾ (in. ³)	BR+/DC+, DC-	BR-	
100...120V AC (±10%) – 1-phase Input, 0...230V 3-phase Output												
22F-V1P6N103	0.2 (0.25)	1.6	90...126	0.8	6.4	10	140M-C2E-C10 140MT-C3E-C10	100-C09 100-E09	1655	___ ⁽⁶⁾	___ ⁽⁶⁾	
22F-V2P5N103	0.4 (0.5)	2.5	90...126	1.1	9.0	15	140M-C2E-C16 140MT-C3E-C16	100-C12 100-E12	1655	___ ⁽⁶⁾	___ ⁽⁶⁾	
22F-V4P5N103	0.75 (1.0)	4.5	90...126	2.2	18.0	30	140M-D8E-C20 140MT-D9E-C20	100-C23 100-E26	1655	___ ⁽⁶⁾	___ ⁽⁶⁾	
22F-V6P0N103	1.1 (1.5)	6.0	90...126	2.9	24.0	40	140M-F8E-C32	100-C30 100-E30	1655	___ ⁽⁶⁾	___ ⁽⁶⁾	
200...240V AC (±10%) – 1-phase Input, 0...230V 3-phase Output												
22F-A1P6N103	0.2 (0.25)	1.6	180...265	0.7	5.3	10	140M-C2E-B63 140MT-C3E-B63	100-C09 100-E09	1655	1000GH-016	___ ⁽⁶⁾	
22F-A2P5N103	0.4 (0.5)	2.5	180...265	1.6	6.5	10	140M-C2E-C10 140MT-C3E-C10	100-C09 100-E09	1655	1000GH-016	___ ⁽⁶⁾	
22F-A4P2N103	0.75 (1.0)	4.2	180...265	2.0	8.2	15	140M-C2E-C16 140MT-C3E-C16	100-C12 100-E12	1655	1000GH-016	___ ⁽⁶⁾	
22F-A8P0N103	1.5 (2.0)	8.0	180...265	5.4	22.3	35	140M-D8E-C25 140MT-D9E-C25	100-C23 100-E26	1655	1000GH-025	___ ⁽⁶⁾	
22F-A011N103	2.2 (3.0)	11.0	180...265	5.9	24.3	40	140M-F8E-C32	100-C30 100-E30	1655	1000GH-025	___ ⁽⁶⁾	
200...240V AC (±10%) – 1-phase Input, 0...230V 3-phase Output, with Filter												
22F-A1P6N113	0.2 (0.25)	1.6	180...265	1.3	5.3	10	140M-C2E-B63 140MT-C3E-B63	100-C09 100-E09	1655	1000GH-016	___ ⁽⁶⁾	
22F-A2P5N113	0.4 (0.5)	2.5	180...265	1.6	6.5	10	140M-C2E-C10 140MT-C3E-C10	100-C09 100-E09	1655	1000GH-016	___ ⁽⁶⁾	
22F-A4P2N113	0.75 (1.0)	4.2	180...265	2.0	8.2	15	140M-C2E-C16 140MT-C3E-C16	100-C12 100-E12	1655	1000GH-016	___ ⁽⁶⁾	
22F-A8P0N113	1.5 (2.0)	8.0	180...265	5.4	22.3	35	140M-D8E-C25 140MT-D9E-C25	100-C23 100-E26	1655	1000GH-025	___ ⁽⁶⁾	
22F-A011N113	2.2 (3.0)	11.0	180...265	5.9	24.3	40	140M-F8E-C32	100-C30 100-E30	1655	1000GH-025	___ ⁽⁶⁾	
200...240V AC (±10%) – 3-phase Input, 0...230V 3-phase Output												
22F-B1P6N103	0.2 (0.25)	1.6	180...265	0.8	1.9	3	140M-C2E-B25 140MT-C3E-B25	100-C09 100-E09	1655	1000GH-016	___ ⁽⁶⁾	
22F-B2P5N103	0.4 (0.5)	2.5	180...265	1.2	2.7	6	140M-C2E-B40 140MT-C3E-B40	100-C09 100-E09	1655	1000GH-016	___ ⁽⁶⁾	
22F-B4P2N103	0.75 (1.0)	4.2	180...265	2.1	4.9	10	140M-C2E-B63 140MT-C3E-B63	100-C09 100-E09	1655	1000GH-016	___ ⁽⁶⁾	
22F-B8P0N103	1.5 (2.0)	8.0	180...265	4.0	9.5	15	140M-C2E-C16 140MT-C3E-C16	100-C12 100-E12	1655	1000GH-025	___ ⁽⁶⁾	
22F-B012N103	2.2 (3.0)	12.0	180...265	6.3	15.0	25	140M-D8E-C20 140MT-D9E-C20	100-C23 100-E26	1655	1000GH-025	___ ⁽⁶⁾	
22F-B017N103	3.7 (5.0)	17.5	180...265	8.8	21.1	35	140M-D8E-C25 140MT-D9E-C25	100-C23 100-E26	1655	1000GH-050	1000GH-050	
22F-B025N104 ⁽¹⁾	5.5 (7.5)	25.0	180...265	11.4	27.2	45	140M-F8E-C32	100-C37 100-E38	3441	1000GH-050	1000GH-050	
22F-B033N104 ⁽¹⁾	7.5 (10.0)	33.0	180...265	16.1	38.5	60	140M-F8E-C45	100-C60 100-E52	3441	1000GH-050	1000GH-050	

Table 12 – Drive Ratings (Continued)

Catalog Number	Output Ratings		Input Ratings				Branch Circuit Protection				DC Fuse ⁽⁵⁾	
	kW (HP)	Amps	Voltage Range	kVA	Amps	Fuses	140M/140MT Motor Protectors ⁽²⁾⁽³⁾	Contactor ⁽³⁾	Min. Enclosure Volume ⁽⁴⁾ (in. ³)	BR+/DC+, DC-	BR-	
380...480V AC (±10%) – 3-phase Input, 0...460V 3-phase Output												
22F-D1P5N103	0.4 (0.5)	1.5	340...528	1.5	1.8	3	140M-C2E-B25 140MT-C3E-B25	100-C09 100-E09	1655	1000GH-016	— ⁽⁶⁾	
22F-D2P5N103	0.75 (1.0)	2.5	340...528	3.0	3.5	6	140M-C2E-B40 140MT-C3E-B40	100-C09 100-E09	1655	1000GH-025	— ⁽⁶⁾	
22F-D4P2N103	1.5 (2.0)	4.2	340...528	5.0	6.0	10	140M-C2E-C10 140MT-C3E-C10	100-C09 100-E09	1655	1000GH-025	— ⁽⁶⁾	
22F-D6P0N103	2.2 (3.0)	6.0	340...528	5.2	6.2	10	140M-C2E-C10 140MT-C3E-C10	100-C09 100-E09	1655	1000GH-025	— ⁽⁶⁾	
22F-D8P7N103	3.7 (5.0)	8.7	340...528	7.0	8.3	15	140M-C2E-C16 140MT-C3E-C16	100-C12 100-E12	1655	1000GH-040	— ⁽⁶⁾	
22F-D013N104 ⁽¹⁾	5.5 (7.5)	13.0	340...528	12.9	15.4	25	140M-D8E-C20 140MT-D9E-C20	100-C23 100-E26	3441	1000GH-040	1000GH-040	
22F-D018N104 ⁽¹⁾	7.5 (10.0)	18.0	340...528	16.3	19.5	30	140M-F8E-C25	100-C23 100-E26	3441	1000GH-050	1000GH-050	
22F-D024N104 ⁽¹⁾	11.0 (15.0)	24.0	340...528	21.7	26.1	40	140M-F8E-C32	100-C30 100-E30	3441	1000GH-050	1000GH-050	
380...480V AC (±10%) – 3-phase Input, 0...460V 3-phase Output, with Filter												
22F-D1P5N113	0.4 (0.5)	1.5	340...528	1.5	1.8	3	140M-C2E-B25 140MT-C3E-B25	100-C09 100-E09	1655	1000GH-016	— ⁽⁶⁾	
22F-D2P5N113	0.75 (1.0)	2.5	340...528	3.0	3.5	6	140M-C2E-B40 140MT-C3E-B40	100-C09 100-E09	1655	1000GH-025	— ⁽⁶⁾	
22F-D4P2N113	1.5 (2.0)	4.2	340...528	5.0	6.0	10	140M-C2E-C10 140MT-C3E-C10	100-C09 100-E09	1655	1000GH-025	— ⁽⁶⁾	
22F-D6P0N113	2.2 (3.0)	6.0	340...528	5.2	6.2	10	140M-C2E-C10 140MT-C3E-C10	100-C09 100-E09	1655	1000GH-025	— ⁽⁶⁾	
22F-D8P7N113	3.7 (5.0)	8.7	340...528	7.0	8.3	15	140M-C2E-C16 140MT-C3E-C16	100-C12 100-E12	1655	1000GH-040	— ⁽⁶⁾	
22F-D013N114 ⁽¹⁾	5.5 (7.5)	13.0	340...528	12.9	15.4	25	140M-D8E-C20 140MT-D9E-C20	100-C23 100-E26	3441	1000GH-040	1000GH-040	
22F-D018N114 ⁽¹⁾	7.5 (10.0)	18.0	340...528	16.3	19.5	30	140M-F8E-C25	100-C23 100-E26	3441	1000GH-050	1000GH-050	
22F-D024N114 ⁽¹⁾	11.0 (15.0)	24.0	340...528	21.7	26.1	40	140M-F8E-C32	100-C30 100-E30	3441	1000GH-050	1000GH-050	

- (1) Catalog suffix ending with '4', such as N104 and N114, indicate that an internal brake IGBT is present.
- (2) The AIC ratings of the Bulletin 140M/140MT Motor Protector Circuit Breakers may vary. See the Motor Protection Circuit Breaker and Motor Circuit Protector Specifications Technical Data, publication [140-TD005](#) or [140M-TD002](#).
- (3) Manual Self-protected (Type E) Combination Motor Controller, UL listed for 208 Wye or Delta, 240 Wye or Delta, 480Y/277 or 600Y/347. Not UL listed for use on 480V or 600V Delta/Delta, corner ground, or high-resistance ground systems.
- (4) When using a Manual Self-protected (Type E) Combination Motor Controller, the drive must be installed in a ventilated or non-ventilated enclosure with the minimum volume specified in this column. Application specific thermal considerations may require a larger enclosure.
- (5) For IEC applications, a DC fuse is mandatory when these terminals are connected. Connect the fuse close to the terminal. Use the specified part number from Hinode.
- (6) This drive rating does not support this function.

Appendix A Supplemental Drive Information

Input/Output Ratings		Approvals	
Output Frequency: 0...400 Hz (Programmable) Efficiency: 97.5% (Typical)		    	
Digital Control Inputs (Input Current = 6 mA)		Analog Control Inputs	
SRC (Source) Mode: 18...24V = ON 0...6V = OFF	SNK (Sink) Mode: 0...6V = ON 18...24V = OFF	4...20mA Analog: 250 Ω input impedance 0...10V DC Analog: 100 kΩ input impedance External Pot: 1...10 kΩ, 2 Watt minimum	
Control Output (Programmable Output, form C relay)			
Resistive Rating: 3.0 A at 30V DC, 125V AC, and 240V AC		Inductive Rating: 0.5 A at 30V DC, 125V AC, and 240V AC	
Recommended Fuses and Circuit Breakers			
Fuse: UL Class J, RK1, T, or Type BS88; 600V (550V) or equivalent.		Circuit Breakers: HMCP or Bulletin 140M/140MT or equivalent.	
Protective Features			
Motor Protection: 171 overload protection - 150% for 60 Secs, 200% for 3 Secs (Provides Class 10 protection)			
Overcurrent: 200% hardware limit, 300% instantaneous fault			
Over Voltage: 100...120V AC Input – Trip occurs at 405V DC bus voltage (equivalent to 150V AC incoming line) 200...240V AC Input – Trip occurs at 405V DC bus voltage (equivalent to 290V AC incoming line) 380...460V AC Input – Trip occurs at 810V DC bus voltage (equivalent to 575V AC incoming line)			
Under Voltage: 100...120V AC Input – Trip occurs at 210V DC bus voltage (equivalent to 150V AC incoming line) 200...240V AC Input – Trip occurs at 210V DC bus voltage (equivalent to 150V AC incoming line) 380...480V AC Input – Trip occurs at 390V DC bus voltage (equivalent to 275V AC incoming line)			
Control Ride-through: Minimum ride-through is 0.5 Secs - Typical value 2 Secs			
Faultless Power Ride-through: 100 milliseconds			
Dynamic Braking			
Internal brake IGBT included with power ratings 5.5 kW (7.5 HP) and 7.5 kW (10.0 HP) for 240V, 3-phase drives and 5.5 kW (7.5 HP), 7.5 kW (10.0 HP), and 11.0 kW (15.0 HP) for 480V, 3-phase drives. See Appendix B for ordering information.			

Category	Specification	
Environment	Altitude	1000 m (3300 ft) max. without derating
	Maximum Surrounding Air Temperature without derating	
	IP20	-10...+50 °C (14...122 °F)
	IP20 zero stacking	-10...+40 °C (14...104 °F)
	Cooling Method	
	Convection	120V, 1-phase, 0.75 kW (1 HP) and below 240V, 1-phase, 0.4 kW (0.5 HP) and below 240V, 3-phase, 0.75 kW (1 HP) and below 480V, 3-phase, 0.75 kW (1 HP) and below
	Fan	All other drive ratings
	Storage Temperature	-40...+85 °C (-40...+185 °F)
	Atmosphere	Important: Drive must not be installed in an area where the ambient atmosphere contains volatile or corrosive gas, vapors, or dust. If the drive is not going to be installed for a period of time, it must be stored in an area where it will not be exposed to a corrosive atmosphere.
	Relative Humidity	0...95% non-condensing
Shock (operating)	15 g peak for 11 ms duration (±1.0ms)	
Vibration (operating)	1 g peak, 5...2000 Hz	

Category	Specification	
Control	Carrier Frequency	2...10 kHz. Drive rating based on 4 kHz.
	Frequency Accuracy	
	Digital Input	Within $\pm 0.05\%$ of set output frequency
	Analog Input	Within 0.5% of maximum output frequency
	Speed Regulation - Open Loop with Slip Compensation	$\pm 2\%$ of base speed across a 40:1 speed range
	Stop Modes	Multiple programmable stop modes including - Ramp, Coast, DC-Brake, Ramp-to-Hold and S Curve
	Acceleration/Deceleration	Two independently programmable acceleration and deceleration times. Each time may be programmed from 0...600 seconds in 0.1 second increments.
	Intermittent Overload	150% Overload capability for up to 1 minute 200% Overload capability for up to 3 seconds
Electronic Motor Overload Protection	Provides class 10 motor overload protection according to NEC article 430 and motor over-temperature protection according to NEC article 430.126 (A) (2). UL 508C File 29572.	
Electrical	Voltage Tolerance	200...240V $\pm 10\%$ 380...480V $\pm 10\%$ 460...600V $\pm 10\%$
	Frequency Tolerance	48...63 Hz
	Input Phases	Three-phase input provides full rating. Single-phase operation provides 35% rated current.
	Displacement Power Factor	0.98 across entire speed range
	Maximum Short-circuit Rating	100,000 Amps Symmetrical
	Actual Short-circuit Rating	Determined by AIC Rating of installed fuse/circuit breaker
	Transistor Type	Isolated Gate Bipolar (IGBT)

Table 13 – PowerFlex 4M Estimated Watts Loss (Rated Load, Speed and PWM)

Voltage	kW (HP)	Watts Loss
100...120V, 1-phase	0.2 (0.25)	17
	0.4 (0.5)	28
	0.75 (1.0)	50
	1.1 (1.5)	76
200...240V, 1-phase	0.2 (0.25)	14
	0.4 (0.5)	25
	0.75 (1.0)	43
	1.5 (2.0)	82
	2.2 (3.0)	109
200...240V, 3-phase	0.2 (0.25)	16
	0.4 (0.5)	26
	0.75 (1.0)	44
	1.5 (2.0)	84
	2.2 (3.0)	115
	3.7 (5.0)	159
	5.5 (7.5)	239
	7.5 (10)	329
380...480V, 3-phase	0.4 (0.5)	24
	0.75 (1.0)	41
	1.5 (2.0)	74
	2.2 (3.0)	92
	3.7 (5.0)	135
	5.5 (7.5)	190
	7.5 (10)	294
	11 (15)	378

Accessories and Dimensions

Product Selection

Table 14 – Catalog Number Description

22F	-	D	8P7	N	1	1	3
Drive		Voltage Rating	Rating	Enclosure	HIM	Emission Class	Type

Table 15 – PowerFlex 4M Drives

Drive Ratings				Catalog Number	
Input Voltage	kW	HP	Output Current (A)	Panel Mount	Frame Size
120V 50/60 Hz 1-phase	0.2	0.25	1.6	22F-V1P6N103	A
	0.4	0.5	2.5	22F-V2P5N103	A
	0.75	1.0	4.5	22F-V4P5N103	B
	1.1	1.5	6.0	22F-V6P0N103	B
240V 50/60 Hz 1-phase	0.2	0.25	1.6	22F-A1P6N103	A
	0.4	0.5	2.5	22F-A2P5N103	A
	0.75	1.0	4.2	22F-A4P2N103	A
	1.5	2.0	8.0	22F-A8P0N103	B
	2.2	3.0	11.0	22F-A011N103	B
240V 50/60 Hz 1-phase with Integral EMC Filter ⁽¹⁾	0.2	0.25	1.6	22F-A1P6N113	A
	0.4	0.5	2.5	22F-A2P5N113	A
	0.75	1.0	4.2	22F-A4P2N113	A
	1.5	2.0	8.0	22F-A8P0N113	B
	2.2	3.0	11.0	22F-A011N113	B
240V 50/60 Hz 3-phase	0.2	0.25	1.6	22F-B1P6N103	A
	0.4	0.5	2.5	22F-B2P5N103	A
	0.75	1.0	4.2	22F-B4P2N103	A
	1.5	2.0	8.0	22F-B8P0N103	A
	2.2	3.0	12.0	22F-B012N103	B
	3.7	5.0	17.5	22F-B017N103	B
	5.5	7.5	25.0	22F-B025N104 ⁽³⁾	C
	7.5	10.0	33.0	22F-B033N104 ⁽³⁾	C
480V 50/60 Hz 3-phase	0.4	0.5	1.5	22F-D1P5N103	A
	0.75	1.0	2.5	22F-D2P5N103	A
	1.5	2.0	4.2	22F-D4P2N103	A
	2.2	3.0	6.0	22F-D6P0N103	B
	3.7	5.0	8.7	22F-D8P7N103	B
	5.5	7.5	13.0	22F-D013N104 ⁽³⁾	C
	7.5	10.0	18.0	22F-D018N104 ⁽³⁾	C
	11.0	15.0	24.0	22F-D024N104 ⁽³⁾	C

Table 15 – PowerFlex 4M Drives (Continued)

Drive Ratings				Catalog Number	
Input Voltage	kW	HP	Output Current (A)	Panel Mount	Frame Size
480V 50/60 Hz 3-phase with Integral EMC Filter ⁽²⁾	0.4	0.5	1.5	22F-D1P5N113	A
	0.75	1.0	2.5	22F-D2P5N113	A
	1.5	2.0	4.2	22F-D4P2N113	A
	2.2	3.0	6.0	22F-D6P0N113	B
	3.7	5.0	8.7	22F-D8P7N113	B
	5.5	7.5	13.0	22F-D013N114 ⁽³⁾	C
	7.5	10.0	18.0	22F-D018N114 ⁽³⁾	C
	11.0	15.0	24.0	22F-D024N114 ⁽³⁾	C

- (1) This filter is suitable for use with a cable length of up to 5 m (16 ft) for EN 55011 Class A and 1 m (3 ft) for EN 55011 Class B environment.
- (2) This filter is suitable for use with a cable length of up to 10 meters (33 feet) for EN 61800-3 second environment.
- (3) Catalog suffix ending with '4', such as N104 and N114, indicate that an internal brake IGBT is supplied.

Table 16 – Dynamic Brake Modules

Drive Ratings				Catalog Number ⁽¹⁾⁽²⁾	Dynamic Brake Fuse ⁽⁴⁾
Input Voltage	kW	HP	Minimum Resistance Ω		
240V 50/60 Hz 3-phase	5.5	7.5	18	AK-R2-030P1K2	1000GH-050
	7.5	10.0	12	AK-R2-030P1K2	1000GH-050
480V 50/60 Hz 3-phase	5.5	7.5	60	AK-R2-120P1K2	1000GH-040
	7.5	10.0	39	AK-R2-120P1K2	1000GH-050
	11.0	15.0	36	AK-R2-120P1K2 ⁽³⁾	1000GH-050

- (1) The resistors listed in this table are rated for 5% duty cycle.
- (2) Use of Rockwell resistors is always recommended. The resistors listed have been carefully selected for optimizing performance in a variety of applications. Alternative resistors may be used, however care must be taken when making a selection. See the PowerFlex Dynamic Braking Resistor Calculator Application Technique, publication [PFLEX-AT001](#).
- (3) Requires two resistors that are wired in parallel.
- (4) For IEC applications, a DC fuse is mandatory when these terminals are connected. Connect the fuse close to the terminal. Use the specified part number from Hinode.

Table 17 – Bulletin 1321-3R Series Line Reactors

Input Voltage	kW	HP	Fundamental Amps	Maximum Continuous Amps	Inductance	Watts Loss	Catalog Number ⁽¹⁾
240V 50/60 Hz 3-phase	0.2	0.25	2	3	12.0 mh	7.5 W	1321-3R2-A
	0.4	0.5	4	6	12.0 mh	21 W	1321-3R4-D
	0.75	1.0	8	12	3.0 mh	29 W	1321-3R8-B
	1.5	2.0	8	12	1.5 mh	19.5 W	1321-3R8-A
	2.2	3.0	12	18	1.25 mh	26 W	1321-3R12-A
	3.7	5.0	18	27	0.5 mh	36 W	1321-3R18-A
	5.5	7.5	25	37.5	0.5 mh	48 W	1321-3R25-A
	7.5	10.0	35	52.5	0.4 mh	49 W	1321-3R35-A
480V 50/60 Hz 3-phase	0.4	0.5	2	3	20.0 mh	11.3 W	1321-3R2-B
	0.75	1.0	4	6	9.0 mh	20 W	1321-3R4-C
	1.5	2.0	4	6	6.5 mh	20 W	1321-3R4-B
	2.2	3.0	8	12	5.0 mh	25.3 W	1321-3R8-C
	3.7	5.0	12	18	2.5 mh	31 W	1321-3R12-B
	5.5	7.5	12	18	2.5 mh	31 W	1321-3R12-B
	7.5	10.0	18	27	1.5 mh	43 W	1321-3R18-B
	11.0	15.0	25	37.5	1.2 mh	52 W	1321-3R25-B

⁽¹⁾ Catalog numbers listed are for 3% impedance open style units. NEMA Type 1 and 5% impedance reactor types are also available. See the 1321 Power Conditioning Products Technical Data, publication [1321-TD001](#).

Table 18 – DC Bus Inductors

Input Voltage	kW	HP	Amps	Inductance mh	MTE Catalog Number ⁽¹⁾
240V 50/60 Hz 3-phase	5.5	7.5	32	0.85	32RB001
	7.5	10.0	40	0.5	40RB001
480V 50/60 Hz 3-phase	5.5	7.5	18	3.75	18RB004
	7.5	10.0	25	4.0	25RB005
	11.0	15.0	32	2.68	32RB003

⁽¹⁾ Use MTE RB series or equivalent inductors.

Table 19 – EMC Line Filters

Drive Ratings			S Type Filter Catalog Number ⁽¹⁾	L Type Filter Catalog Number ⁽³⁾
Input Voltage	kW	HP		
120V 50/60 Hz 1-phase	0.2	0.25	–	22F-RF010-AL
	0.4	0.5	–	22F-RF010-AL
	0.75	1.0	–	22F-RF025-BL
	1.1	1.5	–	22F-RF025-BL
240V 50/60 Hz 1-phase	0.2	0.25	⁽²⁾	22F-RF010-AL
	0.4	0.5	⁽²⁾	22F-RF010-AL
	0.75	1.0	⁽²⁾	22F-RF010-AL
	1.5	2.0	⁽²⁾	22F-RF025-BL
	2.2	3.0	⁽²⁾	22F-RF025-BL
240V 50/60 Hz 3-phase	0.2	0.25	22F-RF9P5-AS	22F-RF9P5-AL
	0.4	0.5	22F-RF9P5-AS	22F-RF9P5-AL
	0.75	1.0	22F-RF9P5-AS	22F-RF9P5-AL
	1.5	2.0	22F-RF9P5-AS	22F-RF9P5-AL
	2.2	3.0	22F-RF021-BS	22F-RF021-BL
	3.7	5.0	22F-RF021-BS	22F-RF021-BL
	5.5	7.5	22F-RF039-CS	22F-RF039-CL
	7.5	10.0	22F-RF039-CS	22F-RF039-CL
480V 50/60 Hz 3-phase ⁽²⁾	0.4	0.5	22F-RF6P0-AS	22F-RF6P0-AL
	0.75	1.0	22F-RF6P0-AS	22F-RF6P0-AL
	1.5	2.0	22F-RF6P0-AS	22F-RF6P0-AL
	2.2	3.0	22F-RF012-BS	22F-RF012-BL
	3.7	5.0	22F-RF012-BS	22F-RF012-BL
	5.5	7.5	22F-RF026-CS	22F-RF026-CL
	7.5	10.0	22F-RF026-CS	22F-RF026-CL
	11.0	15.0	22F-RF026-CS	22F-RF026-CL

⁽¹⁾ This filter is suitable for use with a cable length up to 5 m (16 ft) for Class A and 1 m (3 ft) for Class B environments.

⁽²⁾ These ratings can be ordered with internal “S Type” filters. See the Catalog Number explanation on [page 10](#) and [Table 15](#) for details.

⁽³⁾ This filter is suitable for use with a cable length up to 100 m (328 ft) for Class A and 25 m (82 ft) for Class B environments.

Table 20 – Human Interface Module (HIM) Option Kits and Accessories

Item	Description	Catalog Number
LCD Display, Remote Panel Mount	Digital speed control CopyCat capable IP66 (NEMA Type 4X/12) indoor use only 22-HIM-C2 includes 2.9 m (9.51 ft) cable 22-HIM-C2S includes 2.0 m (6.6 ft) cable	22-HIM-C2 22-HIM-C2S ⁽¹⁾
LCD Display, Remote Handheld	Digital speed control Full numeric keypad CopyCat capable IP30 (NEMA Type 1) Includes 1.0 m (3.3 ft) cable Panel mount with optional Bezel Kit	22-HIM-A3
Bezel Kit	Panel mount for LCD display, remote handheld unit, IP30 (NEMA Type 1)	22-HIM-B1
DSI HIM Cable (DSI HIM to RJ45 cable)	1.0 m (3.3 ft) 2.9 m (9.51 ft)	22-HIM-H10 22-HIM-H30

⁽¹⁾ The 22-HIM-C2S is smaller than the 22-HIM-C2 and cannot be used as a direct replacement.

Table 21 – Communication Option Kits

Item	Description	Catalog Number
External DSI Communications Kit	External mounting kit for 22-COMM-C, 22-COMM-D, 22-COMM-E, 22-COMM-P	22-XCOMM-DC-BASE
External Comms Power Supply	Optional 100...240V AC power supply for external DSI communications kit	20-XCOMM-AC-PS1
Compact I/O Module	3-channel	1769-SM2
DSI Cable	2.0 m (6.6 ft) RJ45 to RJ45 cable, male to male connectors	22-RJ45CBL-C20
Splitter Cable	RJ45 one to two port splitter cable	AK-U0-RJ45-SC1
Terminating Resistors	RJ45 120 Ω resistors (2 pieces)	AK-U0-RJ45-TR1
Terminal Block	RJ45 Two-position terminal block (5 pieces)	AK-U0-RJ45-TB2P

Table 22 – Programming Software

Item	Description
Connected Components Workbench Software	<p>Windows-based software packages for programming and configuring Allen-Bradley drives and other Rockwell Automation products.</p> <p>Compatibility: Microsoft Windows® Server 2012⁽¹⁾, Windows Server 2012 R2, Windows Server 2016⁽¹⁾, Windows Server 2019, Windows 10 IoT Enterprise 2016 LTSC 64-bit, Windows 10 IoT Enterprise 2019 LTSC, Windows 10, and Windows 11⁽²⁾</p> <p>All supported operating systems require .NET Framework 3.5 SP1 to be installed.</p> <p>You can download Connected Components Workbench Standard Edition software for free at rok.auto/pcdc.</p> <p>To purchase Connected Components Workbench Developer Edition software, visit rok.auto/ccw.</p>
DriveExecutive Software (Download as part of the DriveTools SP software package)	<p>Windows-based software package that provides an intuitive means for monitoring or configuring Allen-Bradley drives and communications adapters online and offline.</p> <p>Compatibility: Microsoft Windows 7, Windows 10, and Windows Server 2019</p> <p>You can download DriveTool SP software package at rok.auto/pcdc.</p>

(1) Requires Connected Components Workbench software version 20.01.00 or earlier.

(2) Requires Connected Components Workbench software version 20.01.00 or later.

Product Dimensions



Table 23 – PowerFlex 4M Panel Mount Drives

Ratings are in kW and (HP).

Frame	120V AC – 1-phase	240V AC – 1-phase	240V AC – 3-phase	480V AC – 3-phase
A	0.2 (0.25) 0.4 (0.5)	0.2 (0.25) 0.4 (0.5) 0.75 (1.0)	0.2 (0.25) 0.4 (0.5) 0.75 (1.0) 1.5 (2.0)	0.4 (0.5) 0.75 (1.0) 1.5 (2.0)
B	0.75 (1.0) 1.1 (1.5)	1.5 (2.0) 2.2 (3.0)	2.2 (3.0) 3.7 (5.0)	2.2 (3.0) 3.7 (5.0)
C	—	—	5.5 (7.5) 7.5 (10.0)	5.5 (7.5) 7.5 (10.0) 11.0 (15.0)

Figure 7 – PowerFlex 4M Panel Mount Drives

Dimensions are in millimeters and (inches). Weights are in kilograms and (pounds).




Note:
DIN rail mounting is not applicable to Frame C.

Frame	a	b	c	d	e	f	g	h	i	j	k	Shipping Weight
A	72.0 (2.83)	59.0 (2.32)	174.0 (6.85)	151.6 (5.97)	∅ 5.4 (0.21)	∅ 5.4 (0.21)	5.2 (0.20)	—	136.0 (5.35)	90.9 (3.58)	81.3 (3.20)	1.6 (3.5)
B	100 (3.94)	89.0 (3.50)	174.0 (6.85)	163.5 (6.44)	∅ 5.4 (0.21)	∅ 5.4 (0.21)	5.2 (0.20)	0.5 (0.02)	136.0 (5.35)	90.9 (3.58)	81.3 (3.20)	2.1 (4.6)
C	130.0 (5.12)	116.0 (4.57)	260.0 (10.24)	247.5 (9.74)	∅ 5.5 (0.22)	∅ 5.5 (0.22)	6.0 (0.24)	1.0 (0.04)	180.0 (7.09)	128.7 (5.07)	—	4.8 (10.6)

Figure 8 – Dynamic Brake Modules

Dimensions are in millimeters and (inches).



Frame	Catalog Number
B	AK-R2-030P1K2, AK-R2-120P1K2

Figure 9 – Recommended External Brake Resistor Circuitry





Figure 10 – Bulletin 1321-3R Series Line Reactors

Dimensions are in millimeters and (inches). Weights are in kilograms and (pounds).



Catalog Number	A	B	C	D	E	Weight
1321-3R2-A	112 (4.40)	104 (4.10)	70 (2.75)	50 (1.98)	37 (1.44)	1.8 (4)
1321-3R2-B	112 (4.40)	104 (4.10)	70 (2.75)	50 (1.98)	37 (1.44)	1.8 (4)
1321-3R4-B	112 (4.40)	104 (4.10)	76 (3.00)	50 (1.98)	37 (1.44)	1.8 (4)
1321-3R4-C	112 (4.40)	104 (4.10)	86 (3.38)	60 (2.35)	37 (1.44)	2.3 (5)
1321-3R4-D	112 (4.40)	104 (4.10)	92 (3.62)	66 (2.60)	37 (1.44)	2.7 (6)
1321-3R8-A	152 (6.00)	127 (5.00)	76 (3.00)	53 (2.10)	51 (2.00)	3.1 (7)
1321-3R8-B	152 (6.00)	127 (5.00)	76 (3.00)	53 (2.10)	51 (2.00)	3.6 (8)
1321-3R8-C	152 (6.00)	127 (5.00)	85 (3.35)	63 (2.48)	51 (2.00)	4.9 (11)
1321-3R12-A	152 (6.00)	127 (5.00)	76 (3.00)	53 (2.10)	51 (2.00)	4.1 (9)
1321-3R12-B	152 (6.00)	127 (5.00)	76 (3.00)	53 (2.10)	51 (2.00)	4.5 (10)
1321-3R18-A	152 (6.00)	133 (5.25)	79 (3.10)	54 (2.13)	51 (2.00)	4.1 (9)
1321-3R18-B	152 (6.00)	135 (5.30)	89 (3.50)	63 (2.48)	51 (2.00)	5.5 (12)
1321-3R25-A	183 (7.20)	146 (5.76)	85 (3.35)	60 (2.35)	76 (3.00)	4.9 (11)
1321-3R25-B	183 (7.20)	147 (5.80)	89 (3.50)	60 (2.35)	76 (3.00)	6.4 (14)
1321-3R35-A	193 (7.60)	146 (5.76)	91 (3.60)	66 (2.60)	76 (3.00)	6.3 (14)

Figure 11 – Frame A EMC Line Filters

Dimensions are in millimeters and (inches).

Catalog Numbers: 22F-RF010-AL; 22F-RF9P5-AS, 22F-RF9P5-AL; 22F-RF6P0-AS, 22F-RF6P0-AL




Figure 12 – Frame B EMC Line Filters

Dimensions are in millimeters and (inches).

Catalog Numbers: 22F-RF025-BL; 22F-RF021-BS, 22F-RF021-BL; 22F-RF012-BS, 22F-RF012-BL




Figure 13 – Frame C EMC Line Filters

Dimensions are in millimeters and (inches).

Catalog Number: 22F-RF039-CS, 22F-RF039-CL; 22F-RF026-CS, 22F-RF026-CL




Figure 14 – Remote (Panel Mount) HIM
 Dimensions are in millimeters and (inches).
 Catalog Number: 22-HIM-C2







Figure 15 – Remote (Panel Mount) Small HIM



Dimensions are in millimeters and (inches).

Catalog Number: 22-HIM-C2S




Important: The 22-HIM-C2S is smaller than the 22-HIM-C2 and cannot be used as a direct replacement.

Figure 16 – NEMA Type 1 Bezel
 Dimensions are in millimeters and (inches).
 Catalog Number: 22-HIM-B1



RS-485 (DSI) Protocol

PowerFlex 4M drives support the RS-485 (DSI) protocol to allow efficient operation with Rockwell Automation peripherals. In addition, some Modbus functions are supported to allow simple networking. PowerFlex 4M drives can be multi-dropped on an RS-485 network using Modbus protocol in RTU mode.




For information regarding DeviceNet® or other communication protocols, see the appropriate user manual.

Network Wiring

Network wiring consists of a shielded 2-conductor cable that is daisy chained from node to node.

Figure 17 – Network Wiring Diagram



*Terminal block for Frame A and B drives is shown here.

Only pins 4 and 5 on the RJ45 plug should be wired. The other pins on the PowerFlex 4M RJ45 socket contain power and so on, for other Rockwell Automation peripheral devices and must not be connected.

Wiring terminations on the master controller will vary depending on the master controller used and “TxRxD+” and “TxRxD-” are shown for illustration purposes only. See the master controller’s user manual for network terminations. Note that there is no standard for the “+” and “-” wires, and consequently Modbus device manufacturers interpret them differently. If you have problems with initially establishing communications, try swapping the two network wires at the master controller.

Standard RS-485 wiring practices apply.

- Termination resistors need to be applied at each end of the network cable.
- RS-485 repeaters may need to be used for long cable runs, or if greater than 32 nodes are needed on the network.
- Network wiring should be separated from power wires by at least 0.3 meters (1 foot).
- Network wiring should only cross power wires at a right angle.

I/O Terminal 16 (RS-485 Shield) on the PowerFlex 4M drive must also be connected to PE ground (there are two PE terminals on the drive). See [Figure 5](#) for more information.

Network Common is internally tied to I/O Terminal 04 (Digital Common). Tying I/O Terminal 04 to PE ground may improve noise immunity in some applications.

Parameter Configuration

The following PowerFlex 4M parameters are used to configure the drive to operate on a network.

Parameter	Details	Reference
P106 [Start Source]	Set to 5 "RS485 (DSI) Port" if Start is controlled from the network.	Page 47
P108 [Speed Reference]	Set to 5 "RS485 (DSI) Port" if the Speed Reference is controlled from the network.	Page 49
C302 [Comm Data Rate]	Sets the data rate for the RS485 (DSI) Port. All nodes on the network must be set to the same data rate.	Page 55
C303 [Comm Node Addr]	Sets the node address for the drive on the network. Each device on the network requires a unique node address.	Page 55
C304 [Comm Loss Action]	Selects the drive's response to communication problems.	Page 55
C305 [Comm Loss Time]	Sets the time that the drive will remain in communication loss before the drive implements A105 [Comm Loss Action].	Page 56
C306 [Comm Format]	Sets the transmission mode, data bits, parity and stop bits for the RS485 (DSI) Port. All nodes on the network must be set to the same setting.	Page 56

Supported Modbus Function Codes

The peripheral interface (DSI) used on PowerFlex 4M drives supports some of the Modbus function codes.

Modbus Function Code (Decimal)	Command
03	Read Holding Registers
06	Preset (Write) Single Register
16 (10 Hexadecimal)	Preset (Write) Multiple Registers

Important: Modbus devices can be 0-based (registers are numbered starting at 0) or 1-based (registers are numbered starting at 1). Depending on the Modbus Master used, the register addresses listed on the following pages may need to be offset by +1. For example, Logic Command may be register address 8192 for some master devices (for example, ProSoft 3150-MCM SLC™ Modbus scanner) and 8193 for others (for example, PanelView™ terminals).

Writing (06) Logic Command Data

The PowerFlex 4M drive can be controlled via the network by sending Function Code 06 writes to register address 8192 (Logic Command). [P106](#) [Start Source] must be set to 5 “RS485 (DSI) Port” in order to accept the commands. In addition to being written, register address 8192 can be read using Function Code 03.

Logic Command			
Address (Decimal)	Bit(s)	Description	
8192	0	1 = Stop, 0 = Not Stop	
	1	1 = Start, 0 = Not Start	
	2	1 = Jog, 0 = No Jog	
	3	1 = Clear Faults, 0 = Not Clear Faults	
	5,4	00	No Command
		01	Forward Command
		10	Reverse Command
		11	No Command
	6	Controls the C-form relay when the value of parameter I221 is set to 13. 1 = On, 0 = Off	
	7	1 = MOP Increment, 0 = Not Increment	
	9,8	00	No Command
		01	Accel Rate 1 Enable
		10	Accel Rate 2 Enable
		11	Hold Accel Rate Selected
	11,10	00	No Command
		01	Decel Rate 1 Enable
		10	Decel Rate 2 Enable
		11	Hold Decel Rate Selected
	14,13,12	000	No Command
		001	Freq. Source = P108 [Speed Reference]
010		Freq. Source = A409 [Internal Freq]	
011		Freq. Source = Comms (Addr 8193)	
100		A410 [Preset Freq 0]	
101		A411 [Preset Freq 1]	
110		A412 [Preset Freq 2]	
111		A413 [Preset Freq 3]	
15	1 = MOP Decrement, 0 = Not Decrement		

Writing (06) Reference

The Speed Reference to a PowerFlex 4M drive can be controlled via the network by sending Function Code 06 writes to register address 8193 (Reference). P108 [Speed Reference] must be set to 5 “RS485 (DSI) Port” in order to accept the Speed Reference. In addition to being written, register address 8193 can be read using Function Code 03.

Reference	
Address (Decimal)	Description
8193	A decimal value entered as xxx.x where the decimal point is fixed. For example, a decimal “100” equals 10.0 Hz and “543” equals 54.3 Hz.

Reading (03) Logic Status Data

The PowerFlex 4M Logic Status data can be read via the network by sending Function Code 03 reads to register address 8448 (Logic Status).

Logic Status		
Address (Decimal)	Bit(s)	Description
8448	0	1 = Ready, 0 = Not Ready
	1	1 = Active (Running), 0 = Not Active
	2	1 = Cmd Forward, 0 = Cmd Reverse
	3	1 = Rotating Forward, 0 = Rotating Reverse
	4	1 = Accelerating, 0 = Not Accelerating
	5	1 = Decelerating, 0 = Not Decelerating
	6	1 = Alarm, 0 = No Alarm
	7	1 = Faulted, 0 = Not Faulted
	8	1 = At Reference, 0 = Not At Reference
	9	1 = Reference Controlled by Comm
	10	1 = Operation Cmd Controlled by Comm
	11	1 = Parameters have been locked
	12	Digital Input 1 Status
	13	Digital Input 2 Status
	14	Not Used
15	Not Used	

Reading (03) Feedback

The Feedback (Output Frequency) from the PowerFlex 4M drive can be read via the network by sending Function Code 03 reads to register address 8451 (Feedback).

Feedback ⁽¹⁾	
Address (Decimal)	Description
8451	A xxx.x decimal value where the decimal point is fixed. For example, a decimal “123” equals 12.3 Hz and “300” equals 30.0 Hz.

⁽¹⁾ Returns the same data as Reading (03) Parameter d001 [Output Freq].

Reading (03) Drive Error Codes

The PowerFlex 4M Error Code data can be read via the network by sending Function Code 03 reads to register address 8449 (Drive Error Codes).

		Logic Status
Address (Decimal)	Value (Decimal)	Description
8449	0	No Fault
	2	Auxiliary Input
	3	Power Loss
	4	Undervoltage
	5	Overvoltage
	6	Motor Stalled
	7	Motor Overload
	8	Heatsink Overtemperature
	12	HW Overcurrent (300%)
	13	Ground Fault
	29	Analog Input Loss
	33	Auto Restart Tries
	38	Phase U to Ground Short
	39	Phase V to Ground Short
	40	Phase W to Ground Short
	41	Phase UV Short
	42	Phase UW Short
	43	Phase VW Short
	63	Software Overcurrent
	64	Drive Overload
70	Power Unit Fail	
80	AutoTune Fail	
81	Communication Loss	
100	Parameter Checksum Error	
122	I/O Board Fail	

Reading (03) and Writing (06) Drive Parameters

To access drive parameters, the Modbus register address equals the parameter number. For example, a decimal “1” is used to address Parameter [d001](#) [Output Freq] and decimal “109” is used to address Parameter [P109](#) [Accel Time 1].

Additional Information

Visit www.rockwellautomation.com/en-us/products/hardware/allen-bradley/vfd.html for additional information.

RJ45 DSI Splitter Cable

The PowerFlex 4M drive provides a RJ45 port to allow the connection of a single peripheral device. The RJ45 DSI splitter cable can be used to connect a second DSI peripheral device to the drive.

Connectivity Guidelines




ATTENTION: Risk of injury or equipment damage exists. The peripherals may not perform as intended if these Connectivity Guidelines are not followed. Precautions should be taken to follow these Connectivity Guidelines.


- Two peripherals maximum can be attached to a drive.
- If a single peripheral is used, it must be connected to the Master port (M) on the splitter and configured for “Auto” (default) or “Master.” Parameter 9 [Device Type] on the DSI keypads and Parameter 1 [Adapter Cfg] on the Serial Converter are used to select the type (Auto/Master/Slave).
- If two peripherals will be powered up at the same time, one must be configured as the “Master” and connected to the Master port (M) and the other must be connected as the “Slave” and connected to the Slave port (S).

RJ45 Cable Accessories


RJ45 Splitter Cable –
Catalog Number: AK-U0-RJ45-SC1




RJ45 Two-position Terminal Block Adapter –
Catalog Number: AK-U0-RJ45-TB2P



RJ45 Adapter with Integrated Termination Resistor –
Catalog Number: AK-U0-RJ45-TR1



Connecting an RS-485 Network



Customer supplied RJ45 male-to-RJ45 male cables with wires connected at pins 4 and 5 only.

Both the master (M) and slave (S) ports on the RJ45 Splitter Cable operate as standard RS-485 ports in this configuration.

Notes:

A

AC Supply
 Ground, **14**
 Source, **13**
 Ungrounded, **13**
Advanced Program Group Parameters, **57**
Ambient Temperatures, **12**
Armored Cable, **19**
Auto Rstrt Tries Fault, **74**
Auxiliary Input Fault, **73**

B

Before Applying Power, **33, 34**

C

Cable Length, **23**
Cable, Power, **19**
Catalog Number Explanation, **10**
CE Conformity, **31**
Checklist, Start-Up, **33, 34**
Circuit Breakers
 Input, **16**
Comm Loss Fault, **74**
Command Sources for Start and Speed, **29**
Communications Group Parameters, **55**
Connected Components Workbench, **39**
Contactors, Input, **22**
Control, 2 and 3 Wire, **25, 28**
Conventions, Manual, **8**
Cover, Opening, **11**
Cross Reference, Parameter by Name, **69**

D

Dimensions
 Drive, **90**
 Minimum Clearances, **12**
Display, **34**
Display Group Parameters, **41**

Distribution Systems, Ungrounded, **13**
Drive Frame Size, **8, 90**
Drive Grounding, **14**
Drive Overload Fault, **74**
Drive Ratings, **10, 79**
DriveExecutive, **39**

E

Earthing, *see* *Grounding*
EMC/RFI
 Grounding, Filter, **16**
 Interference, **31**
Enclosure Rating, Changing, **12**
ESD, Static Discharge, **9**

F

Faults
 Auto Rstrt Tries, **74**
 Auxiliary Input, **73**
 Comm Loss, **74**
 Drive Overload, **74**
 Ground Fault, **73**
 Heatsink OvrTmp, **73**
 HW OverCurrent, **73**
 I/O Board Fail, **74**
 Motor Overload, **73**
 Motor Stalled, **73**
 OverVoltage, **73**
 Parameter Checksum, **74**
 Phase Short, **74**
 Phase to Ground Short, **74**
 Power Loss, **73**
 Power Unit, **74**
 SW OverCurrent, **74**
 UnderVoltage, **73**
Filter, RFI, **16**
Frame Designations, **8, 79, 90**
Fuses
 Input, **16**
 Ratings, **79**

G

- General Precautions, **9**
- Ground Fault, **73**
- Grounding
 - Filter, **16**
 - General, **14**

H

- Heatsink OvrTmp Fault, **73**
- HW OverCurrent Fault, **73**

I

- I/O
 - Wiring, **22**
 - Wiring Examples, **25, 28**
- I/O Board Fail Fault, **74**
- Input Contactor, **22**
- Input Fusing, **16**
- Input Potentiometer, **25**
- Input Power Conditioning, **14**
- Installation, **11**
- Integral Keypad, **34**
- Interference, EMC/RFI, **31**

K

- Keypad, **34**

L

- LEDs, **34**

M

- Minimum Clearances, **12**
- Motor Cable Length, **20**
- Motor Overload Fault, **73**
- Motor Stalled Fault, **73**
- motor starter, **16**
- Mounting Options and Clearances, **12**
- MOVs, **13**

O

- Opening the Cover, **11**
- Operating Temperatures, **12**
- Operator Interface, **34**
- OverVoltage Fault, **73**

P

- Parameter
 - Descriptions, **39**
 - Types, **39**
 - Viewing and Editing, **36**
- Parameter Checksum Fault, **74**
- Parameter Cross Reference
 - by Name, **69**
- Parameters
 - Advanced Program Group, **57**
 - Communications Group, **55**
 - Display Group, **41**
 - Program Group, **46**
 - Terminal Block Group, **51**
- PE Ground, **15**
- Phase Short Fault, **74**
- Phase to Ground Fault, **74**
- Potentiometer, Wiring, **25**
- Power Cables/Wiring, **18**
- Power Conditioning, Input, **14**
- Power Loss Fault, **73**
- Power Unit Fault, **74**
- Powering Up the Drive, **33, 34**
- Precautions, General, **9**
- Product Selection, **85**
- Program Group Parameters, **46**
- Programming, **39**
- PTC Analog Input Wiring, **25**

R

- Ratings, **79**
- Reflective Wave Protection, **20**
- Removing Cover, **11**
- Repeated Start/Stop, **22**
- Repeated Start/Stop Precautions, **22**
- RFI, see *EMC/RFI*
- RWR (Reflective Wave Reducer), **20**

S

- Safety Ground, **15**
- Shielded Power Cables, **19**
- Short Circuit Protection, **16**
- Software, **39**

Start and Speed Reference Selection
and Control, **29, 30**

Start/Stop, Repeated, **22**

Start-Up Checklist, **33, 34**

Static Discharge, ESD, **9**

Status LEDs, **34**

Supply Source, AC, **13**

SW OverCurrent Fault, **74**

System Grounding, **14**

T

Terminal Block

I/O, **23**

Power, **22**

Terminal Block Group Parameters, **51**

Three Wire Control, **25, 28**

Two Wire Control, **25, 28**

U

UnderVoltage Fault, **73**

Ungrounded Supply, **13**

Unshielded Power Cables, **19**

W

Watts Loss, **84**

Wiring, **11**

Block Diagram, **24**

I/O, **22**

I/O Examples, **25, 28**

Potentiometer, **25**

Power, **18**

PTC Example, **25**

Notes:

Rockwell Automation Support

Use these resources to access support information.

Technical Support Center	Find help with how-to videos, FAQs, chat, user forums, Knowledgebase, and product notification updates.	rok.auto/support
Local Technical Support Phone Numbers	Locate the telephone number for your country.	rok.auto/phonesupport
Technical Documentation Center	Quickly access and download technical specifications, installation instructions, and user manuals.	rok.auto/techdocs
Literature Library	Find installation instructions, manuals, brochures, and technical data publications.	rok.auto/literature
Product Compatibility and Download Center (PCDC)	Download firmware, associated files (such as AOP, EDS, and DTM), and access product release notes.	rok.auto/pcdc

Documentation Feedback

Your comments help us serve your documentation needs better. If you have any suggestions on how to improve our content, complete the form at rok.auto/docfeedback.

Waste Electrical and Electronic Equipment (WEEE)



At the end of life, this equipment should be collected separately from any unsorted municipal waste.

Rockwell Automation maintains current product environmental compliance information on its website at rok.auto/pec.





Allen-Bradley, Compact I/O, Connected Components Workbench, DriveExecutive, DriveExplorer, DriveTools, expanding human possibility, PanelView, PowerFlex, Rockwell Automation, SLC, and TechConnect are trademarks of Rockwell Automation, Inc.

DeviceNet is a trademark of ODVA, Inc.

Microsoft Windows is a trademark of Microsoft, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş. Kar Plaza İş Merkezi E Blok Kat:6 34752, İçerenköy, İstanbul, Tel: +90 (216) 5698400 EEE Yönetmeliğine Uygundur

Connect with us.    

rockwellautomation.com — expanding **human possibility**[®]

AMERICAS: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000

EUROPE/MIDDLE EAST/AFRICA: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2663 0600

ASIA PACIFIC: Rockwell Automation SEA Pte Ltd, 2 Corporation Road, #04-05, Main Lobby, Corporation Place, Singapore 618494, Tel: (65) 6510 6608

UNITED KINGDOM: Rockwell Automation Ltd., Pitfield, Kiln Farm, Milton Keynes, MK11 3DR, United Kingdom, Tel: (44)(1908) 838-800

Publication 22F-UM001E-EN-E - September 2024

Supersedes Publication 22F-UM001D-EN-E - June 2013

Copyright © 2024 Rockwell Automation, Inc. All rights reserved.