ATS Series INSTRUCTION MANUAL

TCD210139AC

Autonics

Thank you for choosing our Autonics product.

Read and understand the instruction manual and manual thoroughly before using the product.

For your safety, read and follow the below safety considerations before using. For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.

Keep this instruction manual in a place where you can find easily.

The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice. Follow Autonics website for the latest information.

Safety Considerations

• Observe all 'Safety Considerations' for safe and proper operation to avoid hazards.

• Λ symbol indicates caution due to special circumstances in which hazards may occur.

Warning Failure to follow instructions may result in serious injury or death.

- 01. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.) Failure to follow this instruction may result in personal injury, economic loss or fire. 02. Do not use the unit in the place where flammable/explosive/corrosive gas,
- high humidity, direct sunlight, radiant heat, vibration, impact or salinity may be present.

ure to follow this instruction may result in explosion or fire. 03. Install on a device panel to use.

- ailure to follow this instruction may result in fire or electric shock. 04. Do not connect, repair, or inspect the unit while connected to a power source.
- Failure to follow this instruction may result in fire or electric shock. 05. Check 'Connections' before wiring.
- ailure to follow this instruction may result in fire. 06. Do not disassemble or modify the unit. Failure to follow this instruction may result in fire or electric shock.

Caution Failure to follow instructions may result in injury or product damage.

- 01. Use the unit within the rated specifications.
- ilure to follow this instruction may result in fire or product damage 02. Use a dry cloth to clean the unit, and do not use water or organic solvent.
- ailure to follow this instruction may result in fire or electric shock 03. Keep the product away from metal chip, dust, and wire residue which flow into the unit.

Failure to follow this instruction may result in fire or product damage.

Cautions during Use


• Follow instructions in 'Cautions during Use'.

Otherwise, it may cause unexpected accidents.


• In case of DC power input, connect it to the designated power input terminals

considering the polarity Power supply should be insulated and limited voltage/current or Class2, SELV power supply device.

- When applying the power to the timer, apply the rated power at the moment by
- switch and relay, etc. Otherwise, it may cause malfunction.
- When supplying or turning off the power, use a switch or etc. to avoid chattering. · Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power.
- In order to block peripheral current, use isolation transformer which of secondary part is not grounded to supply power to the external input device.



• In order to avoid leakage current flowing, connect resistance and condenser like below Otherwise, it may cause malfunction.



- Do not connect two or more timers with only one input contact or transistor simultaneously
- After turning off the power, change the time range, etc.
- Keep away from high voltage lines or power lines to prevent inductive noise. In case installing power line and input signal line closely, use line filter or varistor at power line and shielded wire at input signal line.
- Do not use near the equipment which generates strong magnetic force or high frequency noise This unit may be used in the following environments.
- Indoors (in the environment condition rated in 'Specifications') Altitude max. 2,000 m - Pollution degree 2
- Installation category II

Ordering Information

This is only for reference, the actual product does not support all combinations. For selecting the specified model, follow the Autonics website.

ATS O -	004
O Plug type 8: 8-pin plug	Power supply 1: 12 VDC==
11: 11-pin plug	2: 24 VAC ~ 50 / 60 Hz, 24 VDC == 4: 100 - 240 VAC ~ 50 / 60 Hz, 24 - 240 VDC ==
O Time range	Output
1: 0.1 to 1	No mark: Time limit DPDT (2c),
3: 0.3 to 3	Time limit SPDT (1c) + Instantaneous SPDT (1c) D: Time limit DPDT (2c) E: Time limit SPDT (1c) + Instantaneous SPDT (1c)

Instruction manual

Product Components


• Product (+ bracket)

Sold Separately

- 8-pin controller socket: PG-08, PS-08(N), PS-M8
- 11-pin controller socket: PG-11, PS-11(N)

Dimensions


• Unit: mm, For the detailed drawings, follow the Autonics website.













Unit Descriptions





Output Operation Mode

For the detailed timing chart for operation output mode, refer to the manual. The output operation mode differs depending on each model

ATS8		ATS11	
Α	Power ON Delay	Α	Signal ON Delay
A1	Power ON Delay 1 (One-shot output)	F	Flicker (OFF Start)
В	Power ON Delay 2	F1	Flicker 1 (ON Start)
F	Flicker (OFF Start)	С	Signal OFF Delay
F1	Flicker 1 (ON Start)	D	Signal ON/OFF Delay
I	Interval	I	Interval

Time Range

Display part	Unit	Range		
Display part		ATS - 1	ATS - 3	
1S	SEC	0.1 to 1	0.3 to 3	
10S	SEC	1 to 10	3 to 30	
1M	MIN	0.1 to 1	0.3 to 3	
10M	MIIN	1 to 10	3 to 30	
1H	HOUR	0.1 to 1	0.3 to 3	
10H	HOUR	1 to 10	3 to 30	

Connections

▲ Caution

ATS8

• Refer to the 'specifications' for checking the power supply and control output. • The ATS11 model: Be sure to use terminal No. 2 as the common terminal to connect terminals No. 5, 6, and 7.


Failure to follow this instruction may result in product malfunction.

 Output operation mode: A, F (4) (5 -**(**3) (6




(4) (5) 3 \bigcirc 0 8 $\overline{}$ SOURCE


Output operation mode: A1, B, F1, I



SOURCE



SOURCE







Specifications

Model	ATS8-	ATS11-DD	ATS11-DDE	
Function	Multi Function Timer			
Return time	\leq 100 ms			
Time operation	Power ON Start	Signal ON Start		
Input	-	START, INHIBIT, RESET		
Min. signal width	-	≈ 50ms		
No-voltage input	-	Short-circuit impedance: $\leq 1 \text{ k}\Omega$ Short-circuit residual voltage: $\leq 0.5 \text{ VDC}$ = Open-circuit impedance: $\geq 100 \text{ k}\Omega$		
Control output	Relay			
Contact type	Time limit DPDT (2c), Instantaneous SPDT (1c) + Time limit SPDT (1c)	Time limit DPDT (2c)	Instantaneous SPDT (1c) + Time limit SPDT (1c)	
Contact capacity	250 VAC~ 3 A, 30 VDC== 3 A resistive load	250 VAC \sim 3 A, 24 VDC== 3 A resistive load		
Error	Repeat: $\leq \pm 0.2\% \pm 10 \text{ ms}$ SET: $\leq \pm 5\% \pm 50 \text{ ms}$ Voltage: $\leq \pm 0.5\%$ Temp: $\leq \pm 2\%$			
Certification				
Unit weight (packaged)	\approx 70 g (\approx 95 g)			
			100 0401/40	
Power supply	12 VDC==	$24\text{VAC}{\sim}50/60\text{Hz},$ $24\text{VDC}{=}\pm10\%$	100 - 240 VAC~ 50 / 60 Hz, 24 - 240 VDC==	
Permissible voltage range	90 to 110 % of rated voltage			
Power consumption	It depends on the plug type and output.			
ATS8-	DC: \leq 1.5 W			

ATS8-	$\rm DC: \le 1.5 W$	$\begin{array}{c c} AC: \leq 4.5 \text{ VA} & AC: \leq 4.2 \text{ VA} \\ DC: \leq 2 \text{ W} & DC: \leq 2 \text{ W} \end{array}$		
ATS11-□□D	DC: \leq 1 W	$\begin{array}{l} \text{AC:} \leq 4 \text{ VA} \\ \text{DC:} \leq 1.5 \text{ W} \end{array}$	$\begin{array}{l} AC: \leq 3.5 \text{ VA} \\ DC: \leq 2 \text{ W} \end{array}$	
ATS11-DDE	DC: \leq 1.5 W	$\begin{array}{l} \text{AC:} \leq 4.5 \text{ VA} \\ \text{DC:} \leq 2 \text{ W} \end{array}$	$\begin{array}{l} AC: \leq 4.2 \text{ VA} \\ DC: \leq 2 \text{ W} \end{array}$	
Insulation resistive	≥ 100 MΩ (500 VDC== megger)			
Dielectric strength	Between the charging part and the case : 3,000 VAC \sim at 50 / 60 Hz for 1 min			
Noise immunity	It depends on the power supply.			
ATS-1	\pm 500 V square-wave noise by noise simulator (pulse width 1 $\mu s)$			
ATS-2				
ATS-4	\pm 2kV square-wave noise by noise simulator (pulse width 1 µs)			
Vibration	0.75 mm double amplitude at frequency of 10 to 55 Hz in each X, Y, Z direction for 1 hour			
Vibration (malfunction)	0.5 mm double amplitude at frequency of 10 to 55 Hz in each X, Y, Z direction for 10 min			
Shock	$300 \text{ m/s}^2 (\approx 30 \text{ G})$ in each X, Y, Z direction for 3 times			
Shock (malfunction)	$100 \text{ m/s}^2 (\approx 10 \text{ G}) \text{ In each X, Y, Z direction for 3 times}$			
Relay life cycle	Mechanical: ≥ 10,000,000 operations Electrical: ≥ 100,000 operations (250 VAC~ 3 A resistive load)			
Ambient temperature	-10 to 55 °C, storage: -25 to 65 °C (no freezing or condensation)			
Ambient humidity	35 to 85 %RH, storage: 35 to 85 %RH (no freezing or condensation)			